

US ROCKIES REGION
Operation Summary Report

Well: SCHLAGEL 23-4		Spud date: 1/20/1994	
Project: COLORADO-WELD-NAD83-UTM13		Site: SCHLAGEL 23-4	Rig name no.: BASIC 1652/1652
Event: ABANDONMENT		Start date: 3/23/2017	End date: 4/11/2017
Active datum: RKB @4,874.99usft (above Mean Sea Level)		UWI: 0/3/N/67/W/4/0/SWNE/6/0/0/0/0/0/0/0	

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
3/21/2017	-							
3/23/2017	6:00 - 7:00	1.00	ABANDP	30	G	P		CREW TRAVEL TO LOCATION, HELD A SAFETY MEETING.
	7:00 - 8:00	1.00	ABANDP	30	A	P		R/U RIG PUMP AND LINES TO WELLHEAD
	8:00 - 8:45	0.75	ABANDP	30	E	P		TP-500, CP-700, SCP-0 PSI, BLOW DOWN WELL TO WORK TANK, CONTROL WELL W/15/15 BBLs OF FRESH/BIO WATER.
	8:45 - 9:30	0.75	ABANDP	30	F	P		FUNTION TEST BOP, N/D PRD/TREE, N/U BOP AND 2.06 TBG EQUIPMENT.
	9:30 - 11:30	2.00	ABANDP	31	I	P		TALLY TOO H W/ 218 JTS.
	11:30 - 14:00	2.50	ABANDP	31	I	P		MIRU ANYTIME TESTING, HYDRO TEST TBG TO 3000PSI TO 7150', ALL GOOD PIPE, RDMO TESTER.
	14:00 - 15:45	1.75	ABANDP	31	I	P		TOOH AND STAND BACK 208 JTS AND L/D 10 JTS ON TRAILER.
	15:45 - 17:30	1.75	ABANDP	31	I	P		TIH WITH CIBP AND SET IT @6850' W/209 JTS, WHEN SETTING CIBP FAULT A JUMP ON TBG AND DUE TO SMALLER PIPE DECIDE TO TOO H TO ENSURE THERE IS NO PARTED TBG UP HIGH.
	17:30 - 19:00	1.50	ABANDP	31	I	P		TOOH AND FOUND THAT WE HAVE OUR PLUG SET AND THE SETTING TOOL JUST CHEER OFF FROM DIFFERENT BREAK UP BUT STILL GOOD FOR THE JOB.
	19:00 - 20:00	1.00	ABANDP	30	G	P		CREW TRAVEL.
3/24/2017	6:00 - 7:00	1.00	ABANDP	30	G	P		CREW TRAVEL TO LOCATION, HELD A SAFETY MEETING
	7:00 - 9:00	2.00	ABANDP	31	I	P		TIH W/OPEN NEED TBG TO 6850' ON WENDY CONDITIONS.
	7:00 - 7:00	0.00	ABANDP	33	G	P		SCP-0 PSI, KEEP IT OPEN WHILE WORK ON WELL.
	9:00 - 10:00	1.00	ABANDP	31	H	P		R/U CIRCULATING EQUIPMENT, ESTABLISH CIRCULATION AND ROLL GAS OUT, PRESSURE TEST CIBP AND CSG TO 2000 PSI, R/D CIRCULATING EQUIPMENT.
	10:00 - 11:00	1.00	ABANDP	51	D	P		MIRU SCHLUMBERGER TO MIX AND PUMP 5 BBLs OF FRESH, 15 SKS OF CEMENT MIX AT 15.8# AND 1.53 YIELD AND DISPLEASE IT W/20 BBLs, RDMO CEMENTERS.
	11:00 - 13:00	2.00	ABANDP	31	I	P		L/D ALL TBG ON TBG TRAILER.
	13:00 - 13:30	0.50	ABANDP	34	M	P		MIRU PIONEER WIRELINE TO RIH AND CUT CSG @4290' , POOH, RDMO WIRELINE.
	13:30 - 14:30	1.00	ABANDP	31	1	P		N/D TBG EQUIPMENT, BOP AND WELLHEAD, UNLAND 3.5 CSG WITH CSG SPEAR, N/U SPOOL, BOP AND 3.5 EQUIPMENT.
	14:30 - 18:00	3.50	ABANDP	31	H	P		R/U CIRCULATING EQUIPMENT, ESTABLISH CIRCULATION AND ROLL GAS, CONDITION HOLE FOR CEMENT JOB, GOT ALL HEAVY MUD OUT.
	18:00 - 19:00	1.00	ABANDP	30	G	P		CREW TRAVEL.
3/25/2017	6:00 - 7:00	1.00	ABANDP	30	G	P		CREW TRAVEL TO LOCATION, HELD A SAFETY MEETING.
	7:00 - 9:00	2.00	ABANDP	31	H	P		CHECK PRESSURE 0 PSI, ESTABLISH CIRCULATION AND CONDITION HOLE.

US ROCKIES REGION
Operation Summary Report

Well: SCHLAGEL 23-4

Spud date: 1/20/1994

Project: COLORADO-WELD-NAD83-UTM13

Site: SCHLAGEL 23-4

Rig name no.: BASIC 1652/1652

Event: ABANDONMENT

Start date: 3/23/2017

End date: 4/11/2017

Active datum: RKB @4,874.99usft (above Mean Sea Level)

UWI: 0/3/N/67/W/4/0/SWNE/6/0/0/0/0/0/0/0

Date	Time Start-End	Duration (hr)	Phase	Code	Sub Code	P/U	MD from (usft)	Operation
	9:00 - 10:30	1.50	ABANDP	51	D	P		MIRU SCHLUMBERGER TO MIX AND PUMP 15 BBLS OF SMS, 152 SKS "40.8 BBLS" MIX AT 15.8# AND 1.51 YIELD, DISPLEASE IT W/39 BBLS
	10:30 - 11:00	0.50	ABANDP	31	I	P		POOH TO 3390' W/90 JTS IN THE HOLE.
	11:00 - 11:30	0.50	ABANDP	31	H	P		R/U CIRCULATING EQUIPMENT AND REVERSE OUT CIRCULATION, R/D CIRCULATING EQUIPMENT.
	11:30 - 13:00	1.50	ABANDP	31	I	P		POOH TO 840' W/ 22 JTS AND L/D REST OF CSG.
	13:00 - 14:30	1.50	ABANDP	31	H	P		R/U CIRCULATING EQUIPMENT AND ROLL HOLE X/2 ANNULAR VOLUMES TO ENSURE NO GAS ON WELL BORN, R/D CIRCULATING EQUIPMENT, DRAIN EQUIPMENT, SWI, SDFWE.
	14:30 - 15:30	1.00	ABANDP	30	G	P		CREW TRAVEL
3/27/2017	6:00 - 7:00	1.00	ABANDP	30	G	P		CREW TRAVEL TO LOCATION, HELD A SAFETY MEETING
	7:00 - 8:00	1.00	ABANDP	35	A	P		MIRU SUMMIT SLICKLINE TO RIH AND TAG SUSSEX CEMENT PLUG @3365', POOH, RDMO.
	8:00 - 9:30	1.50	ABANDP	51	D	P		MIRU SCHLUMBERGER CEMENT CREW, HELD A SAFETY MEETING TO DISCUSS JOB PROCEDURES, MIX AND PUMP 15 BBLS OF SMS, 197SKS "52.6 BBLS" OF CEMENT MIX AT 15.8# AND 1.50 YIELD, DISPLEASE IT WITH 2.7 BBLS OF WATER, RDMO CEMENT CREW.
	9:30 - 11:30	2.00	ABANDP	31	1	P		POOH TO 110' WITH 3 JTS, R/U CIRCULATING EQUIPMENT AND REVERSE OUT CIRCULATION, R/D CIRCULATING EQUIPMENT, L/D REST OF CSG ON TRAILER, N/D CSG EQUIPMENT, BOP AND SPOOL.
	11:30 - 13:00	1.50	ABANDP	46	B	P		LET CEMENT SET.
	13:00 - 14:00	1.00	ABANDP	34	I	P		MIRU PIONEER WIRELINE TO RIH AND TAG CEMENT PLUG @155', POOH, RIH AND SET CIBP @ 80', POOH, RDMO WIRELINE.
	14:00 - 16:00	2.00	ABANDP	30	C	P		R/D RIG PUMP AND LINES, P/U LOCATION, TAKE EQUIPMENT TO NEXT LOCATION, SDFN.
	16:00 - 17:00	1.00	ABANDP	30	G	P		CREW TRAVEL
4/11/2017	12:00 - 13:00	1.00	ABANDP	52		P		pressure tested CIBP, surface casing to 500 psi
	13:00 - 14:00	1.00	ABANDP	53	B	P		dug up surface casing
	14:00 - 15:00	1.00	ABANDP	53	C	P		cut casing 6' below GL, tagged @ 75'
	15:00 - 16:00	1.00	ABANDP	53	B	P		filled casing stub with 36 bags 5000 psi cement
	16:00 - 17:00	1.00	ABANDP	53	A	P		capped casing with a metal plate containing well info
	17:00 - 18:00	1.00	ABANDP	53	B	P		backfilled
	16:30 - 16:30	0.00	ABANDP	50		P		P&A'd OFFLINE. NB/CD.