

Document Number:  
401319432

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Erich Zwaagstra  
 Name of Operator: NOBLE ENERGY INC Phone: (970) 371-7884  
 Address: 1625 BROADWAY STE 2200 Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80202 Email: erich.zwaagstra@nblenergy.com

**For "Intent" 24 hour notice required,** Name: \_\_\_\_\_ Tel: \_\_\_\_\_  
 COGCC contact: Email: \_\_\_\_\_

API Number 05-123-20426-00 Well Number: 14-26  
 Well Name: HSR-SHARKEY  
 Location: QtrQtr: SESW Section: 26 Township: 4N Range: 67W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.277870 Longitude: -104.860977  
 GPS Data:  
 Date of Measurement: 11/05/2008 PDOP Reading: 2.0 GPS Instrument Operator's Name: Renee Doiron  
 Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7166	7186	06/07/2017	B PLUG CEMENT TOP	6816
NIOBRARA	6866	6946	06/07/2017	B PLUG CEMENT TOP	6816

Total: 2 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	708	495	708	0	VISU
1ST	6+1/2	4+1/2	11.60	7,422	150	7,422	5,450	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6816 with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth 6780 with 2 sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 120 sks cmt from 958 ft. to 658 ft. Plug Type: CASING Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 2500 ft. with 198 sacks. Leave at least 100 ft. in casing 2397 CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 (Cast Iron Cement Retainer Depth)

Set 161 sacks half in. half out surface casing from 658 ft. to 0 ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: 908 ft. of 4+1/2 inch casing Plugging Date: 06/14/2017  
 \*Wireline Contractor: Casedhole Solutions \*Cementing Contractor: Halliburton / Basic Energy  
 Type of Cement and Additives Used: Class G Neat 15.8#  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Tagged shoe plug @ 2 ft below GL. First CIBP failed pressure test so set a 2nd CIBP.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Diane Blair  
 Title: Engineering Technician Date: \_\_\_\_\_ Email: diane.blair@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

COA Type	Description

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
401319459	GYRO SURVEY
401319460	CEMENT JOB SUMMARY
401319461	OTHER
401319462	WELLBORE DIAGRAM
401319464	WIRELINE JOB SUMMARY

Total Attach: 5 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)