

## Exhibit E-1 Quiver Injection Fluid Analyses

<u>Well Name</u>	<u>Sample Date</u>	<u>TDS</u>	<u>Production Zone</u>
Pattie #1-2 = Quiver Unit 4	2/6/2009	18,586	Spergen
Tempel #1-12 = Quiver Unit 10	2/6/2009	18,529	Spergen
UPLRC-George #1 = Quiver Unit 6	11/9/2016	33,909	Spergen
UPLRC-George #2	5/3/2000	28,436	Spergen
UPLRC-George A #1 = Quiver Unit 7	11/9/2016	35,323	Spergen
UPLRC-George A #2 = Quiver Unit 2	9/29/2015	56,972	Spergen
UPLRC-George A #2 = Quiver Unit 2	11/9/2016	42,963	Spergen
UPLRC-George A #3 = Quiver Unit 3	11/9/2016	35,878	Spergen
UPLRC-Merwin #1-11 = Quiver Unit 11	11/9/2016	13,441	Spergen
UPLRC-Merwin #2-11 = Quiver Unit 9	11/9/2016	16,145	Spergen
UPLRC-Merwin #4-11 = Quiver Unit 12	11/9/2016	14,417	Spergen
Average of All Samples		28,600	