

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

401351881

Date Received:

07/24/2017

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: CHERYL LIGHT

Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP

Phone: (720) 929-6461

Address: P O BOX 173779

Fax: (720) 929-7461

City: DENVER State: CO Zip: 80217-

Email: CHERYL.LIGHT@ANADARKO.COM

For "Intent" 24 hour notice required,

Name: Carlile, Craig

Tel: (970) 629-8279

COGCC contact:

Email: craig.carlile@state.co.us

API Number 05-123-15591-00

Well Name: YAMAGUCHI

Well Number: P27-16

Location: QtrQtr: SESE Section: 27 Township: 3N Range: 67W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.191050

Longitude: -104.869608

GPS Data:

Date of Measurement: 06/26/2009

PDOP Reading: 3.2

GPS Instrument Operator's Name: Paul Tappy

Reason for Abandonment: ☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 4445

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7334	7350			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	367	210	367	0	VISU
1ST	7+7/8	2+7/8	6.5	7,475	250	7,475	6,580	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7275 with 15 sacks cmt on top. CIPB #2: Depth 80 with 25 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 15 sks cmt from 7275 ft. to 6670 ft. Plug Type: CASING Plug Tagged: ☐
Set 150 sks cmt from 4445 ft. to 4040 ft. Plug Type: OPEN HOLE Plug Tagged: ☒
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 350 sacks half in. half out surface casing from 1015 ft. to 317 ft. Plug Tagged: ☐
Set 25 sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
of _____
*Wireline Contractor: _____ *Cementing Contractor: _____
Type of Cement and Additives Used: _____
Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: CHERYL LIGHT
Title: SR REGULATORY ANALYST Date: 7/24/2017 Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Wolfe, Stephen Date: 9/5/2017

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 3/4/2018

<u>COA Type</u>	<u>Description</u>
	<p>Bradenhead Testing</p> <p>Prior to starting plugging operations, a bradenhead test shall be performed. If the initial shut-in bradenhead pressure is greater than 25 psi, pressure remains at the end of the test or any liquids are present at any time during the test, notify COGCC Engineer for sampling requirements prior to proceeding with the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions, Appendix A: Liquid and Gas Sampling.</p>
	<ul style="list-style-type: none"> • Provide 48 hour notice of plugging MIRU via electronic Form 42. • Casing shall be cut a minimum of 50' below the shoe unless previously approved by COGCC Engineer. • Stub plug will be pumped through production casing after being cut at 4445'. Top of stub plug shall be minimum of 100' shallower than the depth from which the production casing is finally cut and pulled. Stub plug shall be tagged. • Surface casing shoe plug shall extend from a minimum of 50' below the shoe to 50' inside of casing. If there is fluid migration or pressure on the well prior to pumping the surface casing shoe plug contact COGCC Engineer for revised plugging orders before proceeding. • Place a 25 sack plug at the surface, all other plugs shall have at least 100' of cement left in the casing. • Properly abandon flowlines as per Rule 1103.
	<p>Post Plugging Reporting</p> <ul style="list-style-type: none"> • Form 17 Bradenhead Test Report shall be submitted within 10 days of the test. • File electronic Form 42 once flowline abandonment is complete. • Submit Form 6 Subsequent Report of Abandonment, attach gyro of 1/15/15.

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
401351881	FORM 6 INTENT SUBMITTED
401351888	PROPOSED PLUGGING PROCEDURE
401351889	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Public Room	Document verification complete 07/31/17	07/31/2017

Total: 1 comment(s)