

FORM  
6Rev  
12/05

# State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

401407270

Date Received:

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required.

Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Jenifer Hakkarinen

Name of Operator: PDC ENERGY INC

Phone: (303) 8605800

Address: 1775 SHERMAN STREET - STE 3000

Fax:

City: DENVER State: CO Zip: 80203

Email: Jenifer.Hakkarinen@pdce.com

For "Intent" 24 hour notice required,

Name:

Tel:

COGCC contact:

Email:

API Number 05-123-25325-00

Well Name: GUTTERSEN

Well Number: 33-32

Location: QtrQtr: NWSE Section: 32 Township: 3N Range: 63W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☐ Notice of Intent to Abandon☒ Subsequent Report of Abandonment

### Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.180000

Longitude: -104.458500

GPS Data:

Date of Measurement: 06/24/2008

PDOP Reading: 1.7

GPS Instrument Operator's Name: HOLLY TRACY

Reason for Abandonment:

☐ Dry☐ Production Sub-economic☐ Mechanical Problems☐ Other

Casing to be pulled:

☐ Yes☐ No

Estimated Depth:

Fish in Hole:

☐ Yes☐ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☐ No

If yes, explain details below

Details:

### Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6780	6786	08/17/2017	B PLUG CEMENT TOP	6499
NIOBRARA	6549	6555	08/17/2017	B PLUG CEMENT TOP	6499

Total: 2 zone(s)

### Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	807	570	807	0	VISU
1ST	7+7/8	4+1/2	10.5	7,397	240	7,397	5,532	CBL
			Stage Tool	4,847	450	4,850	170	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6499 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set <u>40</u> sks cmt from <u>5094</u> ft. to <u>4578</u> ft.	Plug Type: <u>CASING</u>	Plug Tagged: <input type="checkbox"/>
Set <u>80</u> sks cmt from <u>1007</u> ft. to <u>0</u> ft.	Plug Type: <u>CASING</u>	Plug Tagged: <input type="checkbox"/>
Set <u>35</u> sks cmt from <u>130</u> ft. to <u>0</u> ft.	Plug Type: <u>ANNULUS</u>	Plug Tagged: <input type="checkbox"/>
Set _____ sks cmt from _____ ft. to _____ ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set _____ sks cmt from _____ ft. to _____ ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: 08/17/2017

\*Wireline Contractor: Cased Hole Solution

\*Cementing Contractor: O-Tex

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No

\*ATTACH JOB SUMMARY

Technical Detail/Comments:

Guttersen 33-32 (05-123-25325)/Plugging Procedure  
Producing Formation (Perforations): Niobrara: 6549'-6555' Codell: 6780'-6786'  
TD: 7420' PBTD: 7357'  
Surface Casing: 8 5/8" 24# @ 807' w/ 570 sxs  
Production Casing: 4 1/2" 10.5# @ 7397' w/ 690 sxs cmt (First Stage TOC @ 170'; Second Stage TOC @ 5532' - CBL). DV Tool @ 4837'.

Tubing: 2 3/8" tubing set @ 6767' (6/9/2008).

Procedure:

1. RU Wireline. Remove stage tool set at 4063' (8/12/2008).
2. MIRU pulling unit. Pull 2 3/8" tubing.
3. RU wireline company.
4. TIH with CIBP. Set BP at 6499'. Top with 2 sxs 15.8#/gal CI G cement.
5. TIH with tubing to 5094'. RU cementing company. Mix and pump 40 sxs 15.8#/gal CI G cement down tubing to 4578'.
6. TIH with tubing to 1007'. RU cementing company. Mix and pump 80 sxs 15.8#/gal CI G cement down tubing.
7. TIH w/ 1 1/4" 3.02# CS Hydril stick pipe to 130' in production casing annular space. Mix and pump 35 sxs cement from 130' to surface. Pull 1 1/4" tubing.
8. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_

Print Name: Jenifer Hakkarinen

Title: REg TEch

Date: \_\_\_\_\_

Email: Jenifer.Hakkarinen@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved. \_\_\_\_\_

COGCC Approved:

Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

<u>COA Type</u>	<u>Description</u>
-----------------	--------------------

--	--

**Attachment Check List**

<u>Att Doc Num</u>	<u>Name</u>
--------------------	-------------

401407276	WELLBORE DIAGRAM
401407278	CEMENT JOB SUMMARY

Total Attach: 2 Files

**General Comments**

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
-------------------	----------------	---------------------

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)