

Colorado 4-10 Recompletion (EOR Conversion) Procedure

Sec. 10 T6N R52W

1. Remove pumping equipment from well location.
2. MIRU Pulling Unit.
3. Pull Rods and Tubing.
4. Set CIBP @ 4585' above J sandstone.
5. Run in with 2 7/8" line tubing and 5 1/2" AD-1 Packer.
6. Set packer near 4500' above D sandstone perforations.
7. MIT wellbore.
8. Dump packer fluid down annulus.
9. Complete step-rate injectivity test.
10. Wait on further permitting to inject fluid, and lay water lines.