

Document Number:
401459967

Date Received:
11/15/2017

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Jenifer Hakkarinen

Name of Operator: PDC ENERGY INC Phone: (303) 8605800

Address: 1775 SHERMAN STREET - STE 3000 Fax: _____

City: DENVER State: CO Zip: 80203 Email: Jenifer.Hakkarinen@pdce.com

For "Intent" 24 hour notice required, Name: Pesicka, Conor Tel: (970) 415-0789

COGCC contact: Email: conor.pesicka@state.co.us

API Number 05-123-24085-00

Well Name: BROWN Well Number: 12-2

Location: QtrQtr: SWNW Section: 2 Township: 6N Range: 63W Meridian: 6

County: WELD Federal, Indian or State Lease Number: _____

Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.518140 Longitude: -104.410110

GPS Data:
Date of Measurement: 10/05/2006 PDOP Reading: 2.1 GPS Instrument Operator's Name: H.L.TRACY

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems

Other _____

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6736	6744			
NIOBRARA	6506	6572			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	439	225	439	0	VISU
1ST	7+7/8	4+1/2	10.5	6,962	680	6,962	390	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6456 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 60 sks cmt from 650 ft. to 0 ft. Plug Type: CASING Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Perforate and squeeze at 390 ft. with 90 sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
 Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
 of _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Brown 12-2 (05-123-24085)/Plugging Procedure (Intent)
 Producing Formation (Perforations): Niobrara: 6506'-6572' Codell: 6736'-6744'
 TD: 6991' PBSD: 6921'
 Surface Casing: 8 5/8" 24# @ 439' w/ 225 sxs
 Production Casing: 4 1/2" 10.5# @ 6962' w/ 680 sxs cmt (TOC @ 390' - CBL).

Tubing: 2 3/8" tubing set @ 6721' (10/2/2015).

Proposed Procedure:

1. Run gyro survey.
2. MIRU pulling unit. Pull 2 3/8" tubing.
3. RU wireline company.
4. TIH with CIBP. Set BP at 6456'. Top with 2 sxs 15.8#/gal CI G cement.
5. TIH with perforation gun. Shoot 2 holes for annular squeeze at 390' @ 1 SPF or preferred.
6. TIH with tubing to 650'. RU cementing company. Mix and pump 60 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface. TOOH with tubing.
7. Hook up cement line to cement flange and pump 90 sxs 15.8#/gal CI G cement into annular space. Cement should circulate to surface.
8. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: JEnifer Hakkarinen
 Title: Reg TEch Date: 11/15/2017 Email: Jenifer.Hakkarinen@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved by MIKE

COGCC Approved:

Date: 12/11/2017

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 6/10/2018

COA Type

Description

	Operator shall implement measures to control unnecessary and excessive venting, to protect the health and safety of the public, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.
	Prior to starting plugging operations a bradenhead test shall be performed. 1)If, before opening the bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required. 2)If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required. 3)If sampling is required contact COGCC engineering for a confirmation of plugging requirements prior to placing any plugs. 4)Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. The Form 17 shall be submitted within 10 days of the test.
	1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2) Prior to placing the 650' plug: verify that all fluid migration (liquid or gas) has been eliminated. If evidence of fluid migration or pressure remains, contact COGCC Engineer for an update to plugging requirements. 3) After isolation has been verified, pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours and tag plug – top of plug must be not deeper than 389' and provide minimum 10 sx plug at the surface. Leave at least 100' of cement in the wellbore for each plug. 4) Properly abandon all flowlines. Once flowlines are properly abandoned, file electronic form 42.

Attachment Check List

Att Doc Num

Name

401459967	FORM 6 INTENT SUBMITTED
401459999	WELLBORE DIAGRAM
401460000	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

User Group

Comment

Comment Date

Public Room	Document verification complete 12/01/17	12/01/2017
-------------	---	------------

Total: 1 comment(s)