

FORM  
6Rev  
12/05

# State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number:  401526084			
Date Received:			

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175	Contact Name: Jenifer Hakkarinen
Name of Operator: PDC ENERGY INC	Phone: (303) 8605800
Address: 1775 SHERMAN STREET - STE 3000	Fax:
City: DENVER State: CO Zip: 80203	Email: Jenifer.Hakkarinen@pdce.com
<b>For "Intent" 24 hour notice required,</b> Name: O'Donnell, Shaun Tel: (720) 305-8280 <b>COGCC contact:</b> Email: shaun.odonnell@state.co.us	

API Number 05-123-20238-00	Well Number: 13-10
Well Name: AVERY	
Location: QtrQtr: NWSW Section: 10 Township: 6N Range: 65W Meridian: 6	
County: WELD	Federal, Indian or State Lease Number:
Field Name: WATTENBERG	Field Number: 90750

☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

### Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.498690	Longitude: -104.657560
GPS Data:	
Date of Measurement: 08/25/2006	PDOP Reading: 2.5
GPS Instrument Operator's Name: Holly L. Tracy	
Reason for Abandonment:	
<input type="checkbox"/> Dry	<input checked="" type="checkbox"/> Production Sub-economic
<input type="checkbox"/> Mechanical Problems	
<input type="checkbox"/> Other	
Casing to be pulled:	Estimated Depth:
<input type="checkbox"/> Yes	<input checked="" type="checkbox"/> No
Fish in Hole:	If yes, explain details below
<input type="checkbox"/> Yes	<input checked="" type="checkbox"/> No
Wellbore has Uncemented Casing leaks:	If yes, explain details below
<input type="checkbox"/> Yes	<input checked="" type="checkbox"/> No
Details:	

### Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7120	7130			
Total: 1 zone(s)					

### Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	404	285	404	0	VISU
1ST	7+7/8	4+1/2	10.5	7,320	370	7,320	3,130	CBL
S.C. 1.1				3,012	245	3,012	0	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7070 with 2 sacks cmt on top. CIBP #2: Depth 6721 with 2 sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 35 sks cmt from 3125 ft. to 2700 ft. Plug Type: CASING Plug Tagged: ☐  
Set 60 sks cmt from 700 ft. to 0 ft. Plug Type: CASING Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Avery 13-10 (05-123-20238)/Plugging Procedure (Intent)

Producing Formation: Codell: 7120'-7130'

Upper Pierre Aquifer: 2819'-2985'

TD: 7361' PBTD: 7236'

Surface Casing: 8 5/8" 24# @ 404' w/ 285 sxs

Production Casing: 4 1/2" 10.5# @ 7320' w/ 370 sxs cmt (TOC @ 3130' - CBL). Casing patch @ 3012'. Annular fill cement w/ 245 sxs cmt (TOC @ Surface - Returns to Surface).

Tubing: 2 3/8" tubing set @ 7106' (3/10/2015).

Proposed Procedure:

1. Run gyro survey.
2. MIRU pulling unit. Pull 2 3/8" tubing.
3. RU wireline company.
4. TIH with CIBP. Set BP at 7070'. Top with 2 sxs 15.8#/gal CI G cement.
5. TIH with CIBP. Set BP at 6721'. Top with 2 sxs 15.8#/gal CI G cement.
6. TIH with tubing to 3125'. RU cementing company. Mix and pump 35 sxs 15.8#/gal CI G cement down tubing.
7. Pick up tubing to 700'. Mix and pump 60 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface.
8. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_

Print Name: Jenifer Hakkarinen

Title: Reg Tech

Date: \_\_\_\_\_

Email: Jenifer.Hakkarinen@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved. \_\_\_\_\_

COGCC Approved:

Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: \_\_\_\_\_

**COA Type**

**Description**

--	--

**Attachment Check List**

**Att Doc Num**

**Name**

401526092	WELLBORE DIAGRAM
401526093	WELLBORE DIAGRAM

Total Attach: 2 Files

**General Comments**

**User Group**

**Comment**

**Comment Date**

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)