

## **Procedure**

---

- 1 Contact landowner and state representative 48 hours prior to commencing work on this well
- 2 Build temporary pad and access road for completion rig and cement unit
- 3 Cut off dry hole marker
- 4 Verify pipe size and weld on wellhead flange and riser
- 5 MIRU completion rig
- 6 MU BHA
- 7 RIH to 400'
- 8 Continue to circulate mud to ensure hole clean out
- 9 POOH and LD BHA
- 10 TIH to 400'
- 11 RU cementers
- 12 Pump 140 sx balanced plug from 400' - Surface
- 13 POOH and LD tubing
- 14 RDMO completion rig
- 15 Dump 25 sx cement inside and outside surface casing
- 16 Cut off wellhead and riser to 4' below ground level
- 17 Weld on dry hole marker
- 18 Clean location and reclaim