

Document Number:
401521618

Date Received:
01/22/2018

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: JEANNE VAN SLAMBROUCK

Name of Operator: NOBLE ENERGY INC Phone: (832) 605-3819

Address: 1001 NOBLE ENERGY WAY Fax: _____

City: HOUSTON State: TX Zip: 77070 Email: JEANNE.VANSLAMBROUCK@NBLENERGY.COM

For "Intent" 24 hour notice required, Name: O'Donnell, Shaun Tel: (720) 305-8280

COGCC contact: Email: shaun.odonnell@state.co.us

API Number 05-123-25310-00

Well Name: COOPER Well Number: 23-15

Location: QtrQtr: SWNE Section: 23 Township: 6N Range: 64W Meridian: 6

County: WELD Federal, Indian or State Lease Number: _____

Field Name: OWL CREEK Field Number: 65500

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.475300 Longitude: -104.512640

GPS Data:
Date of Measurement: 07/11/2008 PDOP Reading: 4.6 GPS Instrument Operator's Name: DAVE GIPSON

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems

Other _____

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6814	6826			
NIOBRARA	6647	6668			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	503	265	503	16	VISU
1ST	7+7/8	4+1/2	11.6	6,932	228	6,932	16	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6597 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 2477 ft. to 2177 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 55 sacks half in. half out surface casing from 703 ft. to 0 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: ANGELA FIORE

Title: ENGINEERING TECHNICIAN Date: 1/22/2018 Email: ANGELA.FIORE@NBLENERGY.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HICKEY, MIKE Date: 2/14/2018

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 8/13/2018

COA Type	Description
	<p>Prior to starting plugging operations a bradenhead test shall be performed.</p> <p>1)If, before opening the bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required.</p> <p>2)If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required.</p> <p>3)If sampling is required contact COGCC engineering for a confirmation of plugging requirements prior to placing any plugs.</p> <p>4)Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. The Form 17 shall be submitted within 10 days of the test.</p>
	<p>1)Submit Form 42 electronically to COGCC 48 hours prior to MIRU electronically to COGCC 48 hours prior to MIRU.</p> <p>2)Prior to placing the 703' plug: verify that all fluid migration (liquid or gas) has been eliminated. If evidence of fluid migration or pressure remains, contact COGCC Engineer for an update to plugging requirements. .</p> <p>3)After isolation has been verified, pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours and tag plug – top of plug must be not deeper than 453' and provide minimum 10 sx plug at the surface. Leave at least 100' of cement in the wellbore for each plug.</p> <p>4)Properly abandon all flowlines. Once flowlines are properly abandoned, file electronic form 42.</p>

Attachment Check List

Att Doc Num	Name
401521618	FORM 6 INTENT SUBMITTED
401521914	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group	Comment	Comment Date
Engineer	Operator shall implement measures to control unnecessary and excessive venting, to protect the health and safety of the public, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.	02/14/2018
Public Room	Pass	02/08/2018

Total: 2 comment(s)