



113826

Cement Ticket

Rig #

Third Party

<b>Customer Name</b>	<b>Date Of Service:</b>
Bill Barrett Corporation	3/24/2018

<b>Location</b>	<b>Equipment</b>
Porter #3	C1002

<b>Billing</b>


<b>Description Of Work</b>	<b>Start Time</b> 05:00 am	<b>Stop Time</b> 01:00 pm
Drove to location signed JSA spot in equipment (EOT @400' 2 3/8 Surface casing @181' 10 3/4 ) had safety meeting with rig crew rigged up equipment and pressure tested to 2000 psi followed by mixing and pumping 317sx=65 bbls Of CGNC 15.8 Slurry To surface, rigged down valve and waited on rig crew to nipple down to top off, washed equipment and moved out of location		

Payroll Section						
	Employee	Emp #	Rev Hrs.	Travel Hrs.	Non Rev Hrs.	Total
Supervisor	Jaime, Gustavo	HGR010484	0.00	0.00	0.00	0.00
Operator	Cisneros, Hector	HGR010397	8.00	0.00	0.00	8.00
Derrick	Garcia, Roger	HGR010713	8.00	0.00	0.00	8.00
FloorHand	Sefcovic, Joseph	HGR010822	8.00	0.00	0.00	8.00
FloorHand	Noss, Sean Joseph	HGR011798	8.00	0.00	0.00	8.00
FloorHand	Mendoza, Esteban	HGR010537	8.00	0.00	0.00	8.00
FloorHand	Gurule, James	HGR010449	8.00	0.00	0.00	8.00

No Unreported Incidents Per  
 My Signature

Ranger Tool Pusher

Customer/Agent:

	REV: 0	PAGE: Page 1 of 1	ORIGINAL ISSUE DATE: 9/9/2015	REVISION DATE: N/A
FORM NUMBER: RIG-NA-FM-0003	PREPARED BY: Doug Barnette	REVIEWED BY: Guy Hass	APPROVED BY: Guy Hass	
TITLE: <b>BATCH TRUCK CHECKLIST</b>				

Crew Lead / Supervisor

Roger Garcia

Date

3-24-18

Customer

Bill Barrett

Well Number

Batch Truck - Pre Job		complete
1.1	Check Cement Head	/
1.2	Ensure Jets are clean	/
1.3	Ensure Belly Lines Clear of Cement	//
1.4	Calibrate Densimeter with fresh water	//
1.5	Flush and set Relief Valve to Operating Pressure	/
1.6	Check vacuum breaker on jet mixing assembly	/
1.7	Check kickout gauge and calibration of all pressure gauges	/
1.8	Fluff cement bulk compartments	/
Batch Truck - Post Job		complete
2.1	Clean and Drain Elbow on top of cement truck (jet elbow)	/
2.2	Clean and Drain 4" Valve under triplex	/
2.3	Clean and Drain Triplex pump	/
2.4	Clean and Drain return lines back to tubs	//
2.5	Clean and Drain C pumps	//
2.6	Open 2" Valve under the return line	/
2.7	Open drain between the 2 tubs	//
2.8	Clean and open 4" valves / both sides of batch truck	/
2.9	Remove Pressure Relief Valve clean and inspect	/
2.10	Drain hard line and hoses	/
2.11	Clean and inspect vacuum breakers	/
2.12	Clean and drain Cement mixing head	/
2.13	Leave Cement head fully open	/
2.14	Knock off caps on suction hose (belly line) flush and clean	/
Bulk Trailer - Post Job		complete
3.1	Remove and clean cement product hose	/
3.2	Ensure pressure relief valves are working	/

Completed By:



Supervisor Completion Sign Off:

\_\_\_\_\_

