



Well Summary Report

(Ladd) Packard 1 3/27/2018 06:00 - 3/28/2018 06:00

API 05-123-11062	State/Province Colorado	County Weld	Field Name Non-Operated	Well Status	Total Depth (ftKB)	Primary Job Type Abandon Well
---------------------	----------------------------	----------------	----------------------------	-------------	--------------------	----------------------------------

Time Log						
Start Time	Dur (hr)	End Time	Code	Category	Com	
06:00	1.00	07:00	CTRL	Crew Travel	Rig crew arrives. Start equipment. Fill out JSA.	
07:00	2.25	09:15	SRIG	Rig Up/Down	MIRU Ensign rig 312. Spot in drilling related equipment. NU BOP. Connect pumping iron, spot in pipe trailer and tanks. RU power swivel. Torque up drill collars and 6 1/4 bit sub. Circulate fluid through drill bit.	
09:15	2.50	11:45	CLN	Clean Out Hole	PU/RIH with 6 1/4 rock bit, (6) 3 1/2 OD drill collars and (7) 2 3/8 P-110 5.95# joints of tubing. Circulated down to 410'KB. Circulate clean.	
11:45	0.75	12:30	PULT	Pull Tubing	RD power swivel, LD drill collars and tubing.	
12:30	1.50	14:00	inactive	inactive	RIH with (13) joints of 2 3/8 PH-6 tubing. EOT @ 404'KB. Pump 5 barrels of water. Wait for cementers	
14:00	0.75	14:45	SRIG	Rig Up/Down	NU pumping iron. Held safety meeting.	
14:45	1.25	16:00	CEMT	Cement Squeeze	Mix and pump 215 sacks (44bbbls.) Class 'G' Neat 15.8#, 1.15 yield slurry. Pumped cement returns to surface.	
16:00	1.00	17:00	PULT	Pull Tubing	LD tubing. RD rig. Top off casing with slurry. RD cementers.	
17:00	13.00	06:00	inactive	inactive	Slurry at surface. Finish rigging down equipment.	

(Ladd) Packard 1 3/30/2018 06:00 - 3/31/2018 06:00

API 05-123-11062	State/Province Colorado	County Weld	Field Name Non-Operated	Well Status	Total Depth (ftKB)	Primary Job Type Abandon Well
---------------------	----------------------------	----------------	----------------------------	-------------	--------------------	----------------------------------

Time Log						
Start Time	Dur (hr)	End Time	Code	Category	Com	
06:00	2.00	08:00	LOCL	Lock Wellhead & Secure		
08:00	1.00	09:00	GOP	General Operations	Dig up & remove cellar ring, cut WH, install dry hole marker, backfill hole.	
09:00	21.00	06:00	inactive	inactive		