

FORM
6Rev
05/18State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

401690960

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10261

Contact Name: KEVIN KANE

Name of Operator: BAYSWATER EXPLORATION & PRODUCTION LLC

Phone: (303) 893-2503

Address: 730 17TH ST STE 500

Fax:

City: DENVER

State: CO

Zip: 80202

Email: kkane@bayswater.us

For "Intent" 24 hour notice required,

Name: Precup, Jim

Tel: (303) 726-3822

COGCC contact:

Email: james.precup@state.co.us

API Number 05-001-08160-00

Well Name: ANDERSON

Well Number: 5

Location: QtrQtr: NWNW

Section: 10

Township: 2S

Range: 61W

Meridian: 6

County: ADAMS

Federal, Indian or State Lease Number:

Field Name: SUN

Field Number: 80200

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.896389

Longitude: -104.204167

GPS Data:

Date of Measurement: 12/25/2009

PDOP Reading: 2.7

GPS Instrument Operator's Name: CODY HOBBS

Reason for Abandonment:

☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ Other

Casing to be pulled:

☒ Yes☐ No

Estimated Depth: 1100

Fish in Hole:

☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
D SAND	6740	6758			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	217	200	217	0	VISU
1ST	7+7/8	4+1/2	11.6	6,840	200	6,840	5,700	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 300 sks cmt from 1300 ft. to 0 ft. Plug Type: ANNULUS Plug Tagged: ☒

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 5000 ft. with 50 sacks. Leave at least 100 ft. in casing 4950 CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Proposed Plugging Procedure:

- 1) Perform Bradenhead test. Sample any fluid or gas present on bradenhead and provide to the state.
- 2) MIRU workover rig, pump and tank
- 3) Kill well as necessary with treated water
- 4) Unhang Poolish rod. POOH LD rods & rod pump.
- 5) NDWH, NUBOPE
- 6) Un-land 2 3/8" production tubing, POOH w/ TBG
- 7) RUWL, Run gyro survey
- 8) Run CBL
- 9) RIH & perforate 3 jsf, @ 5,000-5,002. RDWL.
- 10) PU CICR & RIH on 2 3/8" tbg. Set CICR @ 50' above squeeze perforations ~ 4,950'),
- 11) RU Cementers and squeeze perforations with 50 sx cement. Displace cement out retainer, sting out of CICR & dump 2 sx cmt on top of CICR.
- 12) POOH LD TBG.
- 13) Un-land 4 1/2" casing
- 14) Attempt to cut 4 1/2" casing at 1,100' or at the shallowest freepoint,(minimum 450')and TOO H
- 15) RIH with 2 3/8" tubing to 200' below casing stub
- 16) RU cementers
- 17) Pump a 300 sx cement plug from EOT to surface
- 18) Tag up on cement or confirm to surface
- 19) RDMO location with workover rig
- 20) Dig up and cut casing below surface (6'), weld on dry hole marker
- 21) Remove all surface facilities related to the Anderson #5.
- 22) Restore Pad as per state requirements.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: PAUL GOTTLOB
Title: Regulatory & Engin. Tech. Date: _____ Email: paul.gottlob@iptenergyservices.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

COA Type **Description**

--	--

Attachment Check List

Att Doc Num **Name**

401690962	WELLBORE DIAGRAM
401690963	PROPOSED PLUGGING PROCEDURE
401690964	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

User Group **Comment** **Comment Date**

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)