

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Jenifer Hakkarinen
 Name of Operator: PDC ENERGY INC Phone: (303) 8605800
 Address: 1775 SHERMAN STREET - STE 3000 Fax: _____
 City: DENVER State: CO Zip: 80203 Email: Jenifer.Hakkarinen@pdce.com

For "Intent" 24 hour notice required, Name: Evins, Bret Tel: (970) 420-6699
COGCC contact: Email: bret.evins@state.co.us

API Number 05-123-21677-00 Well Number: 31-16
 Well Name: STATE PETERSON
 Location: QtrQtr: NWNE Section: 16 Township: 5N Range: 63W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: 805198
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.404190 Longitude: -104.439780
 GPS Data:
 Date of Measurement: 10/07/2007 PDOP Reading: 2.8 GPS Instrument Operator's Name: Holly L. Tracy
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: 1700
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6728	6736			
Total: 1 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	323	225	323	0	VISU
1ST	7+7/8	4+1/2	10.5	6,909	370	6,909	2,645	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6678 with 2 sacks cmt on top. CIBP #2: Depth 6392 with 2 sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 1815 ft. to 1400 ft. Plug Type: STUB PLUG Plug Tagged:
 Set 407 sks cmt from 600 ft. to 0 ft. Plug Type: OPEN HOLE Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
 Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
 of _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1105 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

State Peterson 31-16 (05-123-21677)/Plugging Procedure (Intent)
 Producing Formation: Codell: 6728'-6736'
 Upper Pierre Aquifer: 460'-1530'
 TD: 6983' PBTD: 6816.8'
 Surface Casing: 8 5/8" 24# @323' w/ 225 sxs cmt
 Production Casing: 4 1/2" 10.5# @ 6909.3' w/ 370 sxs cmt (TOC @ 2645' - CBL).

 Tubing: 2 3/8" tubing set @ 6715' (8/12/2015).
 Proposed Procedure:
 1. MIRU pulling unit. Pull 2 3/8" tubing.
 2. RU wireline company.
 3. TIH with CIBP. Set BP at 6678'. Top with 2 sxs 15.8#/gal CI G cement.
 4. TIH with CIBP. Set BP at 6392'. Top with 2 sxs 15.8#/gal CI G cement.
 5. TIH with casing cutter. Cut 4 1/2" casing at 1700'. Pull cut casing.
 6. TIH with tubing to 1815'. RU cementing company. Mix and pump 255 sxs 15.8#/gal CI G cement w/ 2% CaCl down tubing (Pierre coverage from 1815'-1400').
 7. Pickup tubing to 600'. Mix and pump 407 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface. TOOH with tubing.
 8. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Jenifer Hakkarinen
 Title: Reg Tech Date: _____ Email: Jenifer.Hakkarinen@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

<u>COA Type</u>	<u>Description</u>

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
401735434	WELLBORE DIAGRAM
401735436	WELLBORE DIAGRAM
401735437	GYRO SURVEY

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)