

DE	ET	OE	ES
----	----	----	----

**Replug By Other Operator**

Document Number:  
401782683

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10459 Contact Name: Kaleb Roush  
 Name of Operator: EXTRACTION OIL & GAS INC Phone: (720) 354-4580  
 Address: 370 17TH STREET SUITE 5300 Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80202 Email: kroush@extractionog.com

**For "Intent" 24 hour notice required,** Name: \_\_\_\_\_ Tel: \_\_\_\_\_  
 COGCC contact: Email: \_\_\_\_\_

API Number 05-001-07000-00 Well Number: 1  
 Well Name: POLLARD  
 Location: QtrQtr: SWSW Section: 28 Township: 1S Range: 66W Meridian: 6  
 County: ADAMS Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: BUGLE Field Number: 7800

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 39.930773 Longitude: -104.787640  
 GPS Data:  
 Date of Measurement: 09/01/2018 PDOP Reading: 1.4 GPS Instrument Operator's Name: Derik Drinnen  
 Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other Re-enter to replug  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	8182	8223	07/20/1995	B PLUG CEMENT TOP	8100
Total: 1 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	11+3/4	8+5/8	24	218	160	218	0	VISU
1ST	7+7/8	4+1/2	11.6	8,243	150	8,243	7,637	CALC
S.C. 1.1	7+7/8	4+1/2	11.6	1,289	0	1,289	0	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ 7400 ft. with \_\_\_\_\_ 50 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ 7300 CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ 2100 ft. with \_\_\_\_\_ 50 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ 2000 CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ 25 sacks half in. half out surface casing from \_\_\_\_\_ 300 ft. to \_\_\_\_\_ 0 ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 of \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1105  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Will run CBL to verify cement behind pipe  
 All location photos are in one attachment

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Kaleb Roush  
 Title: Production Engineer Date: \_\_\_\_\_ Email: kroush@extractionog.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

COA Type	Description

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
401782709	WELLBORE DIAGRAM
401782741	LOCATION PHOTO
401785627	SURFACE OWNER CONSENT

Total Attach: 3 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)