

Document Number:  
401814765

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Valerie Danson  
 Name of Operator: PDC ENERGY INC Phone: (970) 506-9272  
 Address: 1775 SHERMAN STREET - STE 3000 Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80203 Email: valerie.danson@pdce.com

**For "Intent" 24 hour notice required,** Name: Kraich, Adam Tel: (970) 420-0536  
 COGCC contact: Email: adam.kraich@state.co.us

API Number 05-123-19421-00 Well Number: 17-33  
 Well Name: FAFOUTIS  
 Location: QtrQtr: SWSW Section: 17 Township: 5N Range: 66W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: 59445  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.394868 Longitude: -104.811519  
 GPS Data:  
 Date of Measurement: 12/19/2006 PDOP Reading: 4.8 GPS Instrument Operator's Name: David Gipson  
 Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7441	7452			

Total: 1 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	407	284	407	0	VISU
1ST	7+7/8	4+1/2	12.6	7,581	635	7,581	0	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7391 with 2 sacks cmt on top. CIBP #2: Depth 7160 with 2 sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 1800 ft. to 1300 ft. Plug Type: CASING Plug Tagged:   
 Set 47 sks cmt from 607 ft. to 0 ft. Plug Type: CASING Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
 Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 of \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1105  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Fafoutis 17-33 (05-123-19421)/Plugging Procedure (Intent)  
 Producing Formation: Codell: 7441'-7452'  
 Upper Pierre Aquifer: 516'-1510'  
 TD: 7595' PBTD: 7546'  
 Surface Casing: 8 5/8" 24# @ 407' w/ 284 sxs  
 Production Casing: 4 1/2" 12.6# @ 7581' w/ 635 sxs cmt (TOC @ Surface' – Well History).  
 Tubing: Unknown tubing depth and specs.  
 Proposed Procedure:  
 1. MIRU pulling unit. Pull tubing.  
 2. RU wireline company.  
 3. Run CBL from 6500' to surface to confirm TOC @ surface. If not at surface contact engineer to proceed.  
 4. TIH with CIBP. Set BP at 7391'. Top with 2 sxs cmt.  
 5. TIH with CIBP. Set BP at 7160'. Top with 2 sxs cmt.  
 6. TIH with tubing to 1800'. RU cementing company. Mix and pump 40 sxs 15.8#/gal CI G cement down tubing (Pierre coverage from 1800'-1300').  
 7. Pick up tubing to 607'. Mix and pump 47 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface. TOOH with tubing.  
 8. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Valerie Danson  
 Title: Reg Tech Date: \_\_\_\_\_ Email: valerie.danson@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_

Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: \_\_\_\_\_

<u>COA Type</u>	<u>Description</u>

### **Attachment Check List**

<u>Att Doc Num</u>	<u>Name</u>
401814787	WELLBORE DIAGRAM
401814788	WELLBORE DIAGRAM
401814789	GYRO SURVEY

Total Attach: 3 Files

### **General Comments**

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)