

Location 324443

EMC MCA Well Prep Checklist

API: Well Name/Number: 16AV

Site Reclaim

Field: Skinner Ridge

WBS Number: UWDCP-A8061-AEF

GPS: 39.536188/-108.327934

Description	Responsible	Date Comp.	Completed by (TYPE Name and Send Via Email)
Well File Research (including last report if available)	P&A Coordinator/PM/ ABN Eng		
Field Well File Check	Rig Field Rep		
If well file information insufficient, discuss with Field Operations personnel	Rig Field Rep/ABN Eng		
WBS Released	PM		
Everything Above This Line Recommended To Be Signed Before Surface Crew Begins Work * (WBS MUST BE RELEASED)			
Hazard Identification (Site Survey)	Rig Field Rep/Surface Crew		
USA Dig Alert (48hrs prior to dig)	Rig Supervisor/Surface Crew		
Hazard Identification (Site Survey Update)	Rig Field Rep/Surface Crew		
Electrical Removed (must be physically verified by Rig Rep)/ Transfer of Custody	OPS/ Surface Crew		
Well Location Prep for Equipment	OPS/Surface Crew		
Verification and Review of Plugging Permit	Rig Field Rep		Permit Expiration Date:
Everything Above This Line MUST Be Signed Before Rig Crew Begins Work			
Well is Ready to Plug (Handoff)	OPS/Surface Crew		
Confirmation that perforation at shoe	Rig Field Rep		
USA Dig Alert (48hrs prior to dig for cut off)	Rig Supervisor/Surface Crew		
Well Ready for Site Restoration (Handoff)	Rig Field Rep		
Everything Above This Line MUST Be Signed Before Surface Crew Begins Work			
Site Restoration Complete 10/26/18	OPS/Surface Crew		
Well Records Closed	Field Rep/Surface Crew/PM/ABN Eng		



16 AV Reclaim completed 10/26/18