

HCW 24-24

Date: 2/24/2016

AFE No: MTG-2016

Daily Completion and Workover Report

DOL: 2

REPT NO. 2	OPERATOR GREAT WESTERN OPERATING COMPANY LLC	FIELD NAME LAPOUDRE	SUPERVISOR / ENGINEER MIKE COLE / PAUL SALAZ	ST NO. 00
SPUD DATE 12/07/2010	API 05-123-31499	STATE COLORADO	COUNTY WELD	DIVISION GREAT WESTERN OPERA

OPERATIONS AT RPT TIME

24 HR SUMMARY

KILL WELL. POOH. RIH WITH RBP AND SET AT 6,592'. LOAD WELLBORE WITH FRESH WATER. STRIP BOPS AND OLD WELLHEAD. INSTALL NEW 5M WELLHEAD. LAND TUBING ON HANGER. EOT WITH ON/OFF TOLL AT 6,484'. INSTALL MASTER VALVE. TEST WELLHEAD TO 2,500 PSI. RDMO STACK RIG.

24 HR FORECAST

RBP SET AT 6,592.83'. TUBING LANDED ON HANGER. EOT TUBING WITH ON/OFF TOOL AT 6,484.7'. RDMO AND STACK OUT RIG. REMOVE MATTS.

GL ELEV 4,754.0 (usft)	RKB 4,770.0 (usft)	FORMATION	TMD 7,292	TVD 7,292	PBTMD 7,233	PBTVD 7,233
AUTH COST /				DAY COST / CUM COST \$12,632 / \$19,996		

CASING DETAILS

ASSEMBLY	SIZE	INST DATE	FROM (usft)	TO (usft)	SIZE	WEIGHT	GRADE	THRDS

TUBING DETAILS

ASSEMBLY	SIZE	INST DATE	FROM (usft)	TO (usft)	SIZE	WEIGHT	GRADE	THRDS
TEMP. BRIDGE PLUG	4.500	02/24/2016	6,592.8	6,597.8	4.000			

PERFORATIONS

FORMATION/ZONE	DATE	SIDETRK #	STATUS	TYPE	TOP (usft)	BASE (usft)

HOURS	DUR (hr)	PHASE	CODE	SUB	DESCRIPTION
06:00 - 06:45	0.75	MTG	MTG P - MITIGATION		CREW TRAVEL
06:45 - 07:00	0.25	MTG	MTG P - MITIGATION		SAFETY MEETING
07:00 - 07:45	0.75	MTG	MTG P - MITIGATION		BRADENHEAD PRESSURE 18 PSI. BLEED OFF BRADENHEAD TO 0 PSI, ALL GAS. TUBING PRESSURE 680 PSI. BLEED OFF TUBING PRESSURE. PUMP 20 BBLS OF FRESH WATER WITH BIOCIDES DOWN TUBING. CASING PRESSURE 140 PSI. BLEED DOWN CASING PRESSURE. PUMP 30 BBLS OF FRESH WATER DOWN BACKSIDE. REMOVE SURFACE EQUIPMENT. INSTALL BOPS.
07:45 - 09:40	1.92	MTG	MTG P - MITIGATION		UNLAND TUBING. LAY DOWN 4' AND 10' PUP JOINTS. POOH STANDING BACK. LAY DOWN 1 SINGLE, SEAT NIPPLE AND NOTCHED COLLAR.. (225 JOINTS)
09:40 - 11:45	2.08	MTG	MTG P - MITIGATION		PICK UP XN NIPPLE, ON/OFF TOOL AND RBP. RIH WITH STANDS. LAY DOWN 14 SINGLES. SET RBP AT 6,592.83'. LOAD WELLBORE WITH FRESH WATER WITH BIOCIDES. TEST RBP TO 500 PSI FOR 10 MINUTES. GOOD TEST. BLEED OFF PRESSURE
11:45 - 13:00	1.25	MTG	MTG P - MITIGATION		LAY DOWN SINGLE. STRIP BOPS AND OLD WELLHEAD. INSTALL 5M WELLHEAD. SCREW INTO TUBING. RELEASE OFF OF RBP. LAY DOWN 4 SINGLES. LAND TUBING ON HANGER. EOT WITH ON/OFF TOOL AT 6,484.7' (206 JOINTS). INSTALL MASTER VALVE. TEST WELLHEAD TO 2,500 PSI FOR 15 MINUTES. GOOD TEST. BLEED OFF PRESSURE.
13:00 - 15:00	2.00	MTG	MTG P - MITIGATION		RDMO, STACK OUT RIG.
15:00 - 06:00	15.00	MTG	MTG P - MITIGATION		RBP SET AT 6,592.83'. TUBING LANDED ON HAGER. EOT TUBING WITH ON/OFF TOOL AT 6,484.7'.