



SRC ENERGY

**Operator:** SRC Energy  
**Well Name:** Schneider 43-36  
**Legal:** SWSE, Section 36, Township 7N, Range 67W  
**Location:** Weld County, CO  
**API:** 05-123-25265  
**Surface:** 8.625" 24# @ 829' **Hole Size:** 12.25" **TOC:** Surface  
**Production:** 4.5" 11.6# @ 7,438' **Hole Size:** 7.875" **TOC:** 3,540' (CBL)  
**Perforations:** 7,310' – 7,330' (Codell)  
**TD:** 7,460'

P&R Procedure

1. Conduct pre-job safety meeting and complete daily JSA
2. Blow down well if necessary, circulate hole with treated water
3. Dig out around wellhead and perform bradenhead test
4. MIRU WO unit, ND wellhead, NU BOP, tally all pipe
5. TIH w/ 4-1/2" 11.6# CIBP, set at 6,948'
6. Pressure test casing to 500 psi for 15 minutes
7. Set 15 sx on top of CIBP (cover 258' above Niobrara top)
8. TIH to 2,500' and perforate casing
9. TIH w/ 4-1/2" 11.6# CICR, set at 2,400'
  - a. Squeeze perfs w/ 70 sx (300' annulus plug & 100' casing plug)
  - b. Release off-of CICR and set 16 sx on top (200' plug)
10. Cut 4.5" casing at 929' and POOH
11. TIH to 979' and pump stub plug (0' – 979')
  - a. 393 sx of 15.8# class G neat 1.15 cu./ft. yield cement
  - b. 150' out of surface casing
  - c. Wait 4 hours and tag plug
12. RDMO WO unit
13. Dig up wellhead and cut off 10' below restored ground level, top off if necessary
14. Weld on cap with ID plate, inscribed with well location, and identity
15. Backfill, clean location
16. P&R complete