

800 GESSNER ROAD  
 SUITE 1000  
 HOUSTON, TX 77024  
 (713) 935-8900  
 (713) 365-8501 (FAX)



22804

**DAILY WORK TICKET**

RRC # \_\_\_\_\_

REPORT # \_\_\_\_\_ HUB METER \_\_\_\_\_ RIG # 005

Customer Name <u>NOBLE</u>		Customer AFE #		Date <u>07/06/11</u>	
Mailing Address		City	State <u>Colo</u>	Zip	County <u>Weld</u>
Field <u>DT</u>	Lease <u>BERNHARDT P.C N36-17</u>	Well		Order #	
Work Description:					
Workover _____	Rod _____	Rod & Tubing _____	Re-entry _____		
Swabbing _____	Tubing <u>2 3/8 in</u>	Completion <input checked="" type="checkbox"/>	P & A _____		

**BILLING**

DESCRIPTION	RATE	TOTAL	WORKOVER EQUIPMENT	QTY.	RATE Hr. / Day / Ea.	TOTAL
RIG & CREW	9 Hrs. @		Catwalk <u>BOP</u>			
EXTRA LABOR	10 Hrs. @		Pipe Racks			
RIG FUEL	Hrs. @		Power Swivel			
PUMP FUEL	Hrs. @		Rod Tongs			
<b>SWABBING EQUIPMENT</b>	<b>QT</b>		Cement Unit			
Swab Tank - Size			Extra Pump			
Swab Cups - Size			Extra Tank			
OSR - Size			Pipe Dope			
Swabbing Acid <u>Bernhard</u>			Mobile Phone			
Per Diem			<b>RECHARGE ITEMS</b>			
Travel Time	<u>50</u>	Stripper Rubbers				
Rod Overshots		Pipe Wipers				
Rod Backoff Tool		Stripper Head <u>1/4</u>				
Winch Truck		Tong Dies				
Bit Subs		Slip Dies				
Port-A-Can		Permits				
Lock-in Flange	<u>1</u>	Safety Valve				
Surcharge -	<u>2000/yr</u>	Base Beam				

MISCELLANEOUS:

TOTAL BILLABLE AMOUNT THIS FIELD RE

**DESCRIPTION OF WORK:**

TIME STARTED 6:00 am

TIME STOPPED 4:00 pm

Crew travel Safety meeting (falling object) Start equip.  
 ✓ pressure 250/325 psi. Blow & well & pump & B/S  
 Circulate gas & R.1.11 to JT # 237 & lag fill @ 7175.  
 C/O & R.1.11 to JT # 237 & lag plug @ 7335 psi P/O  
 & C/O to p.v.t.d JT # 245 @ 7476 psi Roll hole to  
 R & power swivel. & lag & #5 JTS. T.O.O.H w/  
 120 JTS & S.O.F.N. Crew travel.