

FORM
6Rev
05/18State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

402002900

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Valerie Danson

Name of Operator: PDC ENERGY INC

Phone: (970) 506-9272

Address: 1775 SHERMAN STREET - STE 3000

Fax:

City: DENVER State: CO Zip: 80203

Email: valerie.danson@pdce.com

For "Intent" 24 hour notice required,

Name:

Tel:

COGCC contact:

Email:

API Number 05-123-22181-00

Well Name: HINKLE

Well Number: 24-5

Location: QtrQtr: SESW Section: 5 Township: 4N Range: 64W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☐ Notice of Intent to Abandon☒ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.336110

Longitude: -104.576944

GPS Data:

Date of Measurement: 01/15/2010

PDOP Reading: 2.1

GPS Instrument Operator's Name: Brandon Lucason

Reason for Abandonment:

☐ Dry☐ Production Sub-economic☐ Mechanical Problems☐ Other

Casing to be pulled:

☐ Yes☐ No

Estimated Depth:

Fish in Hole:

☐ Yes☐ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☐ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA-CODELL	6680	6976	03/11/2019	B PLUG CEMENT TOP	6630

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	452	320	452	0	VISU
1ST	7+7/8	4+1/2	11.6	7,058	570	7,058	0	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6630 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 30 sks cmt from 1926 ft. to 1460 ft. Plug Type: CASING Plug Tagged: ☐
 Set 79 sks cmt from 1026 ft. to 0 ft. Plug Type: CASING Plug Tagged: ☐
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 2820 ft. with 40 sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at 1450 ft. with 50 sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: 03/11/2019
 of _____

*Wireline Contractor: C&J Energy Services *Cementing Contractor: C&J Energy Services

Type of Cement and Additives Used: Class G 15.8 PPG Cement & Type III 14.8 PPG Portland Cement

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Hinkle 24-5 (05-123-22181)/Plugging Procedure
 Producing Formation: Niobrara/Codell: 6680'-6976'
 Upper Pierre Aquifer: 595'-1490'
 TD: 7106' PBTD: 7025'
 Surface Casing: 8 5/8" 24# @ 452' w/ 320 sxs cmt
 Production Casing: 4 1/2" 11.6# @ 7058' w/ 570 sxs cmt (TOC @ surface - CBL).

Procedure:

1. MIRU pulling unit. Pull 2 3/8" tubing.
2. RU wireline company.
3. TIH with CIBP. Set BP at 6630'. Top with 2 sxs 15.8#/gal CI G cement.
4. TIH with perforation gun. Shoot holes for squeeze at 2820'.
5. TIH w/ tubing to 2925'. RU cementing company. Pump and squeeze 40 sxs 15.8#/gal CI G cement down tubing through holes at 2820'. TOC at 2397'.
6. TIH w/ tubing to 1926'. Mix and pump 30 sxs 14.8#/gal Type III cement down tubing. (Pierre coverage from 1700'-1200'). TOC at 1460'.
7. TIH with perforation gun. Shoot lower holes at 1450' and upper holes 1200' for squeeze.
8. TIH w/ tubing to 1460'. RU cementing company. Pump and squeeze 50 sxs 14.8#/gal Type III cement down tubing through holes at 1450' and 1200'. TOC at 1174'.
9. Pickup tubing to 1026'. Mix and pump 79 sxs 14.8#/gal Type III cement down tubing. Cement circulate to surface.
10. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____

Print Name: Valerie Danson

Title: Reg Tech

Date: _____

Email: valerie.danson@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY:

<u>COA Type</u>	<u>Description</u>
------------------------	---------------------------

--	--

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
---------------------------	--------------------

402002920	CEMENT JOB SUMMARY
402002934	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

<u>User Group</u>	<u>Comment</u>
--------------------------	-----------------------

Comment Date

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)