



Daily Operations

Well Name: FRANK C12-17

Daily Operations

Well Name	API	Job Type	Start Date	Summary
FRANK C12-17	05-123-23455	PLUG AND ABANDON	1/30/2019	MI P&A EQUIPMENT, SM, SPOT IN EQUIPMENT, DAILY INSPECTION, RU P&A EQUIPMENT, CHECK PRESSURE'S, 550/550, SURFACE 0 PSI, BRADENHEAD TEST, TEST BOPE, KILL WELL & CIRCULATE W/172 BBL'S FW, NDWH, NU BOP'S & TEST OVER WELL, RU WORKFLOOR & TONG, UNLAND 2 3/8" 4.7# EUE 8RD TBG, LD 8 JTS ON CAST FBT # 185, SWI, DRAIN UP EQUIPMENT, PU & SECURE LOCATION, SDFN, CREW TRAVEL.
FRANK C12-17	05-123-23455	PLUG AND ABANDON	1/31/2019	CREW TRAVEL, SM, START & WARM UP EQUIPMENT, CHECK PRESSURE'S, 0/0/0, DAILY INSPECTION, SM W/ANYTIME TESTING, RU HYDRO TESTER, TEST & TALLY 2 3/8" 4.7# EUE 8RD TBG OUT, 200 JTS = 100 STANDS TO DERRICK, TOTAL 9 JTS ON CAST FBT # 185, RDMO HYDROTESTER, SM W/SPN WL, RU WL, RIH W/SINKER BAR & TAG @ 6941', POOH, CALL FOR ODERS, STATE APPROVED TO DUMPBAIL 2 SXS @ 6941', RIH W/DB W/2 SXS @ 6941', POOH, RIH W/4.5" CIBP & SET @ 6358', POOH, RDMO WL, TIH W/200 JTS OF 2 3/8" 4.7# EUE 8RD TBG & TAG CIBP @ 6358', CIRCULATE WELL CLEAN, PRESSURE TEST CIBP/CSG TO 1K/15 MINS, END OF 15 MINS 1000 PSI, GOOD TEST, SM W/SPN CEMENTERS, RU & ESTABLISH CIRCULATION MIX & PUMP 20 SXS G NEAT W/SILICA & DISPLACE W/23.1 BBL'S WATER ETOC @ 6009', RDMO CEMENTERS, STANDBACK 40 STANDS = 80 JTS TBG & LD 120 JTS ON FBT # 185, SWI, DRAIN UP EQUIPMENT, SECURE LOC, SDFN, CREW TRAVEL.
FRANK C12-17	05-123-23455	PLUG AND ABANDON	2/1/2019	CREW TRAVEL, SM, START & WARM UP EQUIPMENT, CHECK PRESSURE, 0 PSI CSG & 0 PSI SURFACE CSG, SM W/SPN WL, RU & RIH W/4.5" JET CUTTER & CUT CSG @ 2500', POOH, RDMO WL, CIRCULATE & CONDITION HOLE FOR 2 HRS @ 2.5 BPM, FREE OF OIL & GAS & LARGE CUTTINGS, 5 MIN FLOW CHECK, FLUID WEIGHT 8.6 PPG, ND BOP'S, SM W/RMOR TOOLHAND, UNLAND 4.5" 11.6# CSG, NU BOP'S, CHANGEOVER TO 4.5" HANDLING EQUIPMENT, LD & RECOVERED 59 JTS OF 4.5" 11.6 # CSG, LD ON CAST FBT # 174, CHANGEOVER TO 2 3/8" HANDLING EQUIPMENT, TIH W/80 JTS OF 2 3/8" EUE 8RD 4.7# TBG W/MULE SHOE @ 2568', SM W/SPN CEMENTERS, RU CEMENTERS, TEST LINES & SET P/O @ 1000 PSI, ESTABLISH CIRCULATION W/5 BBL'S FW, 10 BBL'S MUD FLUSH, 5 BBL'S FW, MIX & PUMP 200 SXS OF G NEAT CEMENT = 41 BBL'S SLURRY & DISPLACE W/7 BBL'S, ETOC @ 1993', RDMO CEMENTERS, TOOH W/17 STANDS TO DERRICK = 34 JTS OF 2 3/8" TBG & LD 46 JTS TBG ON CAST FBT # 185, SWI, DRAIN UP EQUIPMENT, PU & SECURE LOCATION, SDFN, CREW TRAVEL.
FRANK C12-17	05-123-23455	PLUG AND ABANDON	2/4/2019	CREW TRAVEL, SM, START & WARM UP EQUIPMENT, DAILY INSPECTION, CHECK PRESSURE, 0 PSI, TIH W/MULE SHOE & 35 JTS OF 2 3/8" 4.7# EUE 8RD TBG @ 1127', SM W/SPN CEMENTERS, RU CEMENTERS & TEST LINES & SET P/O @ 600 PSI, ESTABLISH CIRCULATION W/5 BBL'S FW, 10 BBL'S MUD FLUSH, 5 BBL'S FW, MIX & PUMP 490 SXS OF G NEAT CEMENT TO SURFACE, LD 35 JTS OF 2 3/8" TBG ON FBT # 185, RD WORKFLOOR, WASH UP BOP'S, ND BOP'S, TOP OFF WELL W/20 SXS OG G NEAT CEMENT TO SURFACE, SWI W/NIGHT CAP, RD CEMENTERS, RD P&A EQUIPMENT, READY TO MOVE IN MORNING, SDFN, PU & SECURE LOCATION, CREW TRAVEL.