

Well Name : Cannon 33-24

API # : 121-10714



Photo 1: Opening containment berm at tank battery.



Photo 2: Laying the water tank down to be loaded.

Well Name : Cannon 33-24

API # : 121-10714



Photo 3: Soil under water tank bottom.



Photo 4: Water tank loaded on flatbed trailer.

Well Name : Cannon 33-24
API # : 121-10714



Photo 5: Laying P2 down for loading.



Photo 6: Soil under P2 tank bottom.

Well Name : Cannon 33-24
API # : 121-10714



Photo 7: P2 loaded on trailer.



Photo 8: Excavating the concrete sump.

Well Name : Cannon 33-24
API # : 121-10714



Photo 9: Flow lines inside concrete sump.



Photo 10: Breaking sump up with backhoe.

Well Name : Cannon 33-24

API # : 121-10714



Photo 11: Concrete sump broken up and removed. Flow lines sticking out of dirt wall.



Photo 12: Pulling 3" line from sump to pit completely removing it.