

Document Number:
402072478

Date Received:
06/12/2019

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Jon Lefor

Name of Operator: NOBLE ENERGY INC Phone: (970) 573-1535

Address: 1001 NOBLE ENERGY WAY Fax: _____

City: HOUSTON State: TX Zip: 77070 Email: jon.lefor@nblenrgy.com

For "Intent" 24 hour notice required, Name: Peterson, Tom Tel: (970) 370-1281

COGCC contact: Email: tom.peterson@state.co.us

API Number 05-123-25720-00

Well Name: WEEZER G Well Number: 3-22

Location: QtrQtr: SESW Section: 3 Township: 4N Range: 65W Meridian: 6

County: WELD Federal, Indian or State Lease Number: _____

Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.335955 Longitude: -104.651340

GPS Data:
Date of Measurement: 05/30/2008 PDOP Reading: 2.7 GPS Instrument Operator's Name: BRIAN DEROSE

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems

Other _____

Casing to be pulled: Yes No Estimated Depth: 1228

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7521	7537			
NIOBRARA	7218	7350			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	1,028	665	1,028	0	VISU
1ST	7+7/8	4+1/2	11.60	7,667	1,140	7,667	1,260	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7168 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 55 sks cmt from 4847 ft. to 4177 ft. Plug Type: CASING Plug Tagged:
Set 40 sks cmt from 2500 ft. to 2000 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 405 sacks half in. half out surface casing from 1228 ft. to 13 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Jan Barthel

Title: Operations Tech Date: 6/12/2019 Email: jan.barthel@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Jacobson, Eric Date: 6/18/2019

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 12/17/2019

<u>COA Type</u>	<u>Description</u>
	This well must be plugged and abandoned no later than November 1, 2019.
	WITH KNOWN BRADENHEAD PRESSURE After pumping plug at 2500', shut down and shut well in at minimum 8 hours; verify gas migration has been eliminated. If evidence of gas migration or pressure remains contact COGCC Engineer for an update to plugging orders.
	If there has not been a reported Bradenhead test within 60 days of plugging this well, prior to starting plugging operations, a Bradenhead test shall be performed. 1) If, before opening the Bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required, and the COGCC engineering staff must be contacted. 2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required. 3) If sampling is required contact COGCC engineering for a confirmation of plugging requirements prior to placing any plugs. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. The Form 17 shall be submitted within 10 days of the test.
	1) Provide 48 hour notice of plugging MIRU via electronic Form 42. 2) Prior to placing the 1228' plug: verify that all fluid migration (liquid or gas) has been eliminated. If evidence of fluid migration or pressure remains, contact COGCC Engineer for an update to plugging orders. 3) After isolation has been verified, pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours then tag plug – must be at 978' or shallower and provide 10 sack plug at surface. 4) Leave at least 100' of cement in the wellbore for each plug. 5) Properly abandon on-location flowlines as per Rule 1105. File electronic Form 42 once abandonment is complete. Within 30 days of an operator completing abandonment requirements for an off-location flowline or crude oil transfer line, the operator must submit a Flowline Report, Form 44.
	Operator shall implement measures to control venting, to protect health and safety, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
402072478	FORM 6 INTENT SUBMITTED
402072483	WELLBORE DIAGRAM
402072484	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Well File Verification	Pass	06/18/2019
Engineer	Deepest Water Well within 1 Mile – 100' SB5 Base of Fox Hills - 247'	06/14/2019
Permit	-Confirmed as-drilled well location. -Production reporting up-to-date. -Confirmed productive interval, docnum: 1938012. -Reviewed WBDs. -Pass	06/13/2019

Total: 3 comment(s)