

FORM
6
Rev
05/18

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 402213124			
Date Received:			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: <u>69175</u>	Contact Name: <u>Valerie Danson</u>
Name of Operator: <u>PDC ENERGY INC</u>	Phone: <u>(970) 506-9272</u>
Address: <u>1775 SHERMAN STREET - STE 3000</u>	Fax: _____
City: <u>DENVER</u> State: <u>CO</u> Zip: <u>80203</u>	Email: <u>valerie.danson@pdce.com</u>
For "Intent" 24 hour notice required, Name: <u>Evins, Bret</u> Tel: <u>(970) 420-6699</u>	
COGCC contact: Email: <u>bret.evins@state.co.us</u>	

API Number: <u>05-123-23177-00</u>	Well Number: <u>22-2</u>
Well Name: <u>WELLS RANCH</u>	
Location: QtrQtr: <u>SENW</u> Section: <u>2</u> Township: <u>5N</u> Range: <u>63W</u> Meridian: <u>6</u>	
County: <u>WELD</u> Federal, Indian or State Lease Number: _____	
Field Name: <u>WATTENBERG</u> Field Number: <u>90750</u>	

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.430750 Longitude: -104.405810

GPS Data:
Date of Measurement: 10/16/2006 PDOP Reading: 1.7 GPS Instrument Operator's Name: H.L. TRACY

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____

Casing to be pulled: Yes No Estimated Depth: 1660

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6647	6653			
Total: 1 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	406	225	406	0	VISU
1ST	7+7/8	4+1/2	10.5	6,841	415	6,841	2,724	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6597 with 2 sacks cmt on top. CIBP #2: Depth 6329 with 2 sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 92 sks cmt from 1710 ft. to 1360 ft. Plug Type: STUB PLUG Plug Tagged:
 Set 189 sks cmt from 606 ft. to 0 ft. Plug Type: OPEN HOLE Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
 Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Cut and Cap Date: _____
 of _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1105 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Wells Ranch 22-2 (05-123-23177)/Plugging Procedure (Intent)
 Producing Formation: Codell: 6647'-6653'
 Upper Pierre Aquifer: 900'-1560'
 TD: 6854' PBTD: 6826'
 Surface Casing: 8 5/8" 24# @ 406' w/ 225 sxs
 Production Casing: 4 1/2" 10.5# @ 6841' w/ 415 sxs cmt (TOC @ 2724' - CBL).
 Tubing: Unknown tubing depth.
 Proposed Procedure:
 1. MIRU pulling unit. Pull tubing string.
 2. RU wireline company.
 3. TIH with CIBP. Set BP at 6597'. Top with 2 sxs cmt.
 4. TIH with CIBP. Set BP at 6329'. Top with 2 sxs cmt.
 5. TIH with casing cutter. Cut 4 1/2" casing at 1660'. Pull cut casing.
 6. TIH with tubing to 1710'. RU cementing company. Mix and pump 92 sxs 15.8#/gal CI G cement w/ 2% CaCl down tubing (stub and Pierre Base coverage from 1710'-1360').
 7. Pick up tubing to 606'. RU cementing company. Mix and pump 189 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface. TOOH with tubing.
 8. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Valerie Danson
 Title: Reg Tech Date: _____ Email: valerie.danson@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

COA Type **Description**

--	--

Attachment Check List

Att Doc Num **Name**

402213195	WELLBORE DIAGRAM
402213199	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group **Comment**

Comment Date

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)