

FORM
6

Rev
02/20

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

402382663

Date Received:

04/28/2020

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10110 Contact Name: Kapri McMillan
 Name of Operator: GREAT WESTERN OPERATING COMPANY LLC Phone: (970) 364-2826
 Address: 1001 17TH STREET #2000 Fax: _____
 City: DENVER State: CO Zip: 80202 Email: kcmcmillan@gwp.com

For "Intent" 24 hour notice required, Name: Santistevan, Brittani Tel: (720) 471-1110
COGCC contact: Email: brittani.santistevan@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-123-26173-00
 Well Name: WINDSOR Well Number: 35-2
 Location: QtrQtr: NWSW Section: 35 Township: 6N Range: 67W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.442660 Longitude: -104.867590
 GPS Data: GPS Quality Value: 2.2 Type of GPS Quality Value: _____ Date of Measurement: 01/03/2014
 GPS Instrument Operator's Name: C. VANMATRE
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: 2500
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7064	7084			
Total: 1 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	503	350	503	0	CALC
1ST	7+7/8	4+1/2	11.6	7,197	542	7,197	3,466	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7000 with 25 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set <u>25</u>	sks cmt from	<u>4200</u>	ft. to	<u>3870</u>	ft.	Plug Type: <u>CASING</u>	Plug Tagged: <input type="checkbox"/>
Set <u>100</u>	sks cmt from	<u>2550</u>	ft. to	<u>2192</u>	ft.	Plug Type: <u>STUB PLUG</u>	Plug Tagged: <input type="checkbox"/>
Set <u>125</u>	sks cmt from	<u>1500</u>	ft. to	<u>1050</u>	ft.	Plug Type: <u>OPEN HOLE</u>	Plug Tagged: <input type="checkbox"/>
Set _____	sks cmt from	_____	ft. to	_____	ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set _____	sks cmt from	_____	ft. to	_____	ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 320 sacks half in. half out surface casing from 1050 ft. to 0 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Cut and Cap Date: _____
 of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

Procedure:

- 1 Contact COGCC
- 2 MIRU
- 3 Blow down and kill well
- 4 NDWH/NUBOP
- 5 TOO H w/ tubing, stand back
- 6 RIH & set CIBP @ 7000'
- 7 Roll hole clean & pressure test to 1000 psi
- 8 Pump 25 sx Thermal 35 on top of plug @ 7000'
- 9 PU to 4200'
- 10 Pump 25 sx Class G balanced plug @ 4200' (calc TOC 3870')
- 11 Verify all fluid migration has been stopped
- 12 Release flowback separator and flare stack if no longer needed
- 13 Cut & pull casing @ 2500'
- 14 Pump stub plug from 2550' w/ 100 sx AGM 4,2 (est TOC @ 2192')
- 15 WOC 4 hours, tag plug, check for migration
- 16 PU to 1500' and pump 125 sx AGM to est TOC @ 1050'
- 17 WOC 8 hours, monitor and record bradenhead pressure in OpenWells
- 18 RIH tag plug, if flow has ceased, continue with operations
- 19 If flow is present, call engineer to discuss next steps.
- 20 Pump 375 sx Class G from 1050' to surface
- 21 RIH tag, top off w/ cement as needed
- 22 RDMO
- 23 Cut & cap casing 4' - 6' below GL w/ plate (Well Name, API, Legal Location)

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Renee Kendrick
Title: SR Regulatory Analyst Date: 4/28/2020 Email: rkendrick@gwp.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: JENKINS, STEVE Date: 5/1/2020

CONDITIONS OF APPROVAL, IF ANY: Expiration Date: 10/31/2020

COA Type	Description
	<p>For Wells with known Bradenhead pressures:</p> <ol style="list-style-type: none">1) Provide 48-hour notice of plugging MIRU via electronic Form 42.2) The plug at 2550' needs to be placed and have an 8-hour WOC to assure that all fluid migration has been stopped. If that doesn't isolate the flow, additional attempts in front of the surface shoe plug will need to be attempted. Other downhole potential squeeze opportunities may need to be looked at before the 1050' plug.3) Prior to placing the 1050' plug: verify that all fluid migration (liquid or gas) has been eliminated. If evidence of fluid migration or pressure remains, contact COGCC Engineer for an update to plugging orders.4) After isolation has been verified, pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours then tag plug – must be at 453' or shallower and provide 10 sx plug at the surface. Leave at least 100' of cement in the casing for each plug.5) Properly abandon flowlines as per Rule 1105. File electronic Form 42 once abandonment is complete. Within 30 days of an operator completing abandonment requirements for an off-location flowline or crude oil transfer line, the operator must submit a Flowline Report, Form 44.6) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed.7) After placing the shallowest hydrocarbon isolating plug (2550'), operator must wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC engineering before continuing operations.
	<p>Operator shall implement measures to control venting, to protect health and safety, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.</p>
	<p>Prior to starting plugging operations a Bradenhead test shall be performed if there has not been a reported Bradenhead test within the 60 days immediately preceding the start of plugging operations.</p> <ol style="list-style-type: none">1) If, before opening the Bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required.2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required. <p>The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.</p>
	<p>Submit Operator's Monthly Production Reports (Form 7) required for compliance with Rule 309 within 30 days.</p> <p>•Missing 1/2018 & 2/2018.</p>

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
402382663	FORM 6 INTENT SUBMITTED
402382676	WELLBORE DIAGRAM
402382678	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	1) Deepest Water Well within 1 mile = 840'. 2) Fox Hills Bottom- N/A, per SB5.	05/01/2020
Permit	•Permitting review complete and task passed.	05/01/2020

Total: 2 comment(s)