

Well Name : State B1

API # : 075-05083



Photo 1: Well sign.



Photo 2: View of location prior to start of task.

Well Name : State B1  
API # : 075-05083



Photo 3: View of rods left on site after well plugging.



Photo 4: Rods loaded and removed from location.

Well Name : State B1  
API # : 075-05083



Photo 5: View of tubing left on location after well plugging.



Photo 6: Tubing loaded and removed from location.

Well Name : State B1  
API # : 075-05083



Photo 7: Crew breaking bolts loose to disassemble pumping unit.



Photo 8: Removing walking beam and pitman arms from unit.

Well Name : State B1

API # : 075-05083



Photo 9: Sampson post removed from unit.



Photo 10: Pumping unit base loaded for removal.

Well Name : State B1

API # : 075-05083



Photo 11: Walking beam, horsehead, and Sampson post loaded for removal.



Photo 12: View of site after pumping unit removed.

Well Name : State B1

API # : 075-05083



Photo 13: Excavating production flow line.



Photo 14: Excavated flow line.

Well Name : State B1

API # : 075-05083



Photo 15: Flowline cut off and cement plugged. Foam ball placed in front of and behind cement to keep it in place.



Photo 16: Backfilled and dressed site.