

(303) 894-2100 (COGCC)
Ext. 5105 (PM Ofc.)
(970) 302-1024 (PM Cell)

TIME	DAILY WORK RECORD
7:30 AM	Crew start.
7:50	Rig start up.
8:00	Wireline on location. Rigging up.
10:30	Start pumping water into well at low rate for pressure test.
11:00	Wireline complete. Set 2 plugs and set 3 sx cement on top of each plug.
11:40	Well loaded and pressured up for pressure test. Pressure test good.
12:30	Change Order: Rig up wire line to run CBL.
2:30	Change Order: CBL completed.
2:30	Wire line tool change and into well for perforations at 1050' and 419'. Rig crew draining pump and lines.
3:00	Wire line rig down complete.
3:30	Well and location secured. Depart location with rod trailer. SDFN.
Notes:	

POSITION	NAME	RIG	TRAVEL	TOTAL
OPERATOR	Jason			0
DERRICK	Rafo			0
CREWMAN	Sal			0
CREWMAN	Armondo			0
CREWMAN				0

WELL RECORD	
Type Well Head	
Packer Settings	
Type Packer	
No. Jts. Tubing	
Pump Out	

Size Rods	No.Rods	Size Subs	No.Sub

		\$ -	\$ -
		\$ -	\$ -
		\$ -	\$ -
Other			\$ -
Total			\$ -

On Site Task Mgr.	Cal St. John	Approved By:	Date:
-------------------	--------------	--------------	-------