



Daily Operations

Well Name: GUTTERSEN D33-23

Daily Operations

Well Name	API	Job Type	Start Date	Summary
GUTTERSEN D33-23	05-123-23720	PLUG AND ABANDON	1/22/2020	<p>IWP- 0 PSI ON SURFACE CASING 100 PSI ON CASING 100 PSI ON TUBING</p> <p>CREW TRAVEL. HELD SAFETY MEETING IN DOG HOUSE. (RIG BROKE DOWN). RU HARDLINE. PRESSURE TEST HARDLINE, PIPE AND BLIND RAMS. RU SERVICE UNIT. ROLLED HOLE WITH 125BBLS OF FRESH WATER. ND WELLHEAD. NU BOP'S. PRESSURE TESTED STACK. RU FLOOR. STOOD BACK ---- JOINTS OF 2 3/8 4.7# J-55 8RD EUE TUBING. SHUT WELL IN. DRAINED HARDLINE AND PUMP. LOCKED OUT WELL, BOP'S AND TANKS. SHUT DOWN (HIGH WIND). CREW TRAVEL.</p>
GUTTERSEN D33-23	05-123-23720	PLUG AND ABANDON	1/23/2020	<p>IWP- 0 PSI ON SURFACE CASING 0 PSI ON CASING</p> <p>CREW TRAVEL. HELD SAFETY MEETING IN DOG HOUSE. CHECKED PRESSURE. TIH WITH HYDRO MECH CIBP AND 211 JOINTS OF 2 3/8 4.7# J-55 8RD EUE TUBING. EOT 6948'. SET CIBP. ROLLED HOLE WITH 130BBLS OF FRESH WATER. PRESSURE TESTED CASING/CIBP TO 500 PSI FOR 15 MIN (HELD). LAID DOWN 211 JOINTS OF 2 3/8 4.7# J-55 8RD EUE TUBING ON CAST TRAILER 177. RD FLOOR. ND BOP'S. ND THREADED WELLHEAD. SHUT WELL IN. LOCKED/TAGGED OUT WELL. DRAINED HARDLINE AND PUMP. RD HARDLINE. RD SERVICE UNIT. CLEANED UP LOCATION. GOT READY TO MOVE.</p>
GUTTERSEN D33-23	05-123-23720	PLUG AND ABANDON	2/10/2020	<p>MIRU SCHLUMBERGER RIGLESS P&A EQUIPMENT. IWP- CSG 0 PSI & SURFACE 0 PSI. TEST EQUIPMENT. RIH W/ DUMP BAILER AND DUMP BAIL 2 SKS CEMENT ON TOP OF THE CIBP @ 6948' KB. POOH W/ DUMP BAILER. RIH AND SET 2 CIBP, THE 1ST @ 6666' KB AND THE 2ND @ 4066' KB. DUMP BAIL 2 SKS OF CEMENT ON TOP OF BOTH PLUGS. (NOTE: THE 1ST PLUG TOOK OVER HOUR TO GET DOWN HOLE DUE TO SOMETHING LEFT IN THE HOLE THAT KEPT HANGING US UP BUT WE WERE ABLE TO GET THE PLUG DOWN AND SET). (NOTE: HAD A LATE START TODAY DUE TO MORNING MEETING / TRAINING). SWI, SDFD, CREW TO THE YARD.</p>
GUTTERSEN D33-23	05-123-23720	PLUG AND ABANDON	2/11/2020	<p>CREW TO LOCATION: IWP- CSG 0 PSI & SURFACE 0 PSI. RIH W/ PERF GUN AND SHOOT SQZ HOLES @ 2500' KB. POOH W/ WIRELINE. CATCH CIRCULATION W/ 10 BFW. MIX AND PUMP 10 BBLS MUD FLUSH, 185 SKS G NEAT W/ 2% CC (38 BBLS 15.8 PPG). DISPLACE W/ 29 BFW AND SWI. RIH W/ PERF GUN DOWN TO 997' KB. PUT 500 PSI ON THE WELL. SHOOT SQZ HOLES @ 997' KB. POOH W/ WIRELINE. ROLL THE HOLE CLEAN. SWI, SDFD, CREW TO THE YARD.</p>
GUTTERSEN D33-23	05-123-23720	PLUG AND ABANDON	2/12/2020	<p>CREW TO LOCATION: IWP- CSG 0 PSI & SURFACE 0 PSI. (PERF'S @ 997' KB). CATCH CIRCULATION W/ 10 BFW. MIX AND PUMP 339 SKS G NEAT W/ 2% CC (70 BBLS 15.8 PPG). DISPLACE W/ 1/4 BFW AND SWI. (NOTE: WE HAD THIN MUD IN THE RETURNS). R/D AND MOVE OFF LOCATION.</p>