

Well Name : Coggins 1 -10

API # : 039-06383



Photo 1: Location sign at tank battery.



Photo 2: Disconnected lines for treaters inside heater treater shed.

Well Name : Coggins 1 -10

API # : 039-06383



Photo 3: Tearing down heater treater shed.



Photo 4: Laying down disconnected treaters for haul off and removal.

Well Name : Coggins 1 -10

API # : 039-06383



Photo 5: One of three anchors located and removed.



Photo 6: View inside unused tank after hatch removed.

Well Name : Coggins 1 -10

API # : 039-06383



Photo 7: Excavating flow line risers at heater treater site.



Photo 8: Cement plugging flow lines for abandonment.

Well Name : Coggins 1 -10

API # : 039-06383



Photo 9: Excavating flow lines on E side of meter run shed.



Photo 10: Cement plugging risers for abandonment.

Well Name : Coggins 1 -10

API # : 039-06383



Photo 11: Backfilled and dressed excavation site on E side of meter run shed.



Photo 12: Backfilling excavation site at heater treater site.

Well Name : Coggins 1 -10
API # : 039-06383



Photo 13: Backfilled and dressed excavation at heater treater site.



Photo 14: Loading heater treater for haul off.

Well Name : Coggins 1 -10

API # : 039-06383



Photo 15: Treater, pipe, pipe fittings, and debris loaded for removal from location.



Photo 16: View of redressed excavation sites.

Well Name : Coggins 1 -10

API # : 039-06383



Photo 17: View of erosion gully off NE side of location.



Photo 18: Additional view of erosion gully looking further down slope.

Well Name : Coggins 1 -10

API # : 039-06383



Photo 19: View from inside erosion gully looking up slope.



Photo 20: View from inside erosion gully looking at top of erosion.