

FORM  
6Rev  
02/20

# State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

402311100

Date Received:

02/12/2020

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Valerie Danson

Name of Operator: PDC ENERGY INC

Phone: (970) 506-9272

Address: 1775 SHERMAN STREET - STE 3000

Fax:

City: DENVER State: CO Zip: 80203

Email: valerie.danson@pdce.com

For "Intent" 24 hour notice required,

Name:

Tel:

COGCC contact:

Email:

Type of Well Abandonment Report:



Notice of Intent to Abandon



Subsequent Report of Abandonment

API Number 05-123-27288-00

Well Name: ZAHOUREK

Well Number: 22-31

Location: QtrQtr: SENW

Section: 31

Township: 7N

Range: 63W

Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

### Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.532390

Longitude: -104.482610

GPS Data: GPS Quality Value: 2.3 Type of GPS Quality Value: PDOP

Date of Measurement: 12/11/2006

GPS Instrument Operator's Name: HOLLY L TRACY

Reason for Abandonment:



Dry



Production Sub-economic



Mechanical Problems

☐ Other

Casing to be pulled:



Yes



No

Estimated Depth:

Fish in Hole:



Yes



No

If yes, explain details below

Wellbore has Uncemented Casing leaks:



Yes



No

If yes, explain details below

Details:

### Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	6931	6941	01/14/2020	B PLUG CEMENT TOP	6881

Total: 1 zone(s)

### Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	544	300	544	0	VISU
1ST	7+7/8	4+1/2	10.5	7,113	662	7,113	0	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6881 with 2 sacks cmt on top. CIBP #2: Depth 6580 with 2 sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 35 sks cmt from 1920 ft. to 1400 ft. Plug Type: CASING Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 65 sacks half in. half out surface casing from 744 ft. to 0 ft. Plug Tagged: ☒

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Cut and Cap Date: 01/15/2020  
of \_\_\_\_\_

\*Wireline Contractor: SureFire Wireline Services

\*Cementing Contractor: NexTier

Type of Cement and Additives Used: Type III 14.8 PPG Portland Cement

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

#### Technical Detail/Comments:

Zahourek 22-31 (05-123-27288)/Plugging Procedure

Producing Formation: Codell: 6931'-6941'

Upper Pierre Aquifer: 560'-1640'

TD: 7141' PBTD: 6965'

Surface Casing: 8 5/8" 24# @ 544' w/ 300 sxs

Production Casing: 4 1/2" 10.5# @ 7113' w/ 662 sxs cmt (TOC @ Surface' - CBL).

#### Procedure:

1. MIRU pulling unit. Pull 2 3/8" tubing.
2. RU wireline company.
3. TIH with CIBP. Set BP at 6881'. Top with 2 sxs 15.8#/gal CI G cement.
4. TIH with CIBP. Set BP at 6580'. Top with 2 sxs 15.8#/gal CI G cement.
5. TIH with tubing to 1920'. RU cementing company. Mix and pump 35 sxs 14.8#/gal Type III cement down tubing (Pierre coverage from 1900'-1400'). TOC at 1400'.
6. Pickup tubing to 744'. Mix and pump 65 sxs 14.8#/gal Type III cement down tubing. Cement circulate to surface.
7. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Valerie Danson

Title: Reg Tech Date: 2/12/2020 Email: valerie.danson@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Haverkamp, Curtis

Date: 10/1/2020

**CONDITIONS OF APPROVAL, IF ANY:****COA Type****Description**

--	--

**Attachment Check List****Att Doc Num****Name**

402311100	FORM 6 SUBSEQUENT SUBMITTED
402311149	CEMENT JOB SUMMARY
402311150	OPERATIONS SUMMARY
402311151	WELLBORE DIAGRAM

Total Attach: 4 Files

**General Comments****User Group****Comment****Comment Date**

Engineer	Form 7s reporting PA status. GPS coordinates appear accurate. Line status = abandoned. Casing and cement depths consistent with Form6-Intent. Procedure and wellbore diagram consistent with Form6-Intent.  Enforcement review: No Form17 documenting pre-P&A bradenhead test.	10/01/2020
----------	---	------------

Total: 1 comment(s)