

Form 6 General Comments: Airco Federal #2 PnA

9/22/20 Open Braidenhead valve, 15 psi. Bleed off with no flow or pressure build up. Pore ½ gallon water down valve and hear water falling.

9/24/20 Set CIBP @ 2115 and pressure test 640 psi for 15 minutes. Pump 8 sxs cement on top of CIBP Plug #1 (2046-2115).

9-25-20 Pump 11 sxs Plug #2 (545-587).

9-28-20 Tag 11 sx plug #2 at 545. Pump additional 8 sxs. Final csg shoe plug #2 (450-587).

9-29-20 Pump 10 sx Surface Plug #3 (0-95). Cut off csg, measure braidenhead cement top 7' below ground level. Install PnA marker 2' below GL. Note reclamation will add additional 3-5 ft of surface fill.

All spacer fluid was fresh water mixed with corrosion inhibitor.