

FORM  
6Rev  
02/20State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

402439493

Date Received:

07/08/2020

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 81480

Contact Name: Kathleen Spring

Name of Operator: THOMAS L SPRING LLC

Phone: (303) 771-1889

Address: 7400 E ORCHARD RD STE 106-S

Fax:

City: GREENWOOD State: CO Zip: 80111

Email: kathleenspring3@gmail.com

For "Intent" 24 hour notice required,

Name: Welsh, Brian

Tel: (719) 325-6919

COGCC contact:

Email: brian.welsh@state.co.us

Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number 05-061-06749-00

Well Name: STATE BOCK

Well Number: 2

Location: QtrQtr: NESE Section: 31 Township: 20S Range: 48W Meridian: 6

County: KIOWA

Federal, Indian or State Lease Number:

Field Name: MCCLAVE

Field Number: 53600

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 38.272560 Longitude: -102.823560

GPS Data: GPS Quality Value: 2.1 Type of GPS Quality Value: PDOP Date of Measurement: 06/26/2012

GPS Instrument Operator's Name: Tom Haskell

Reason for Abandonment: ☐ Dry ☒ Production Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
MORROW	4804	4815			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	322	200	322	0	VISU
1ST	7+7/8	4+1/2	10.5	4,805	285	4,805	3,290	CBL
S.C. 1.1				3,005	440	3,010	1,070	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4690 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 10 sks cmt from 370 ft. to 270 ft. Plug Type: CASING Plug Tagged: ☒

Set 10 sks cmt from 1200 ft. to 1100 ft. Plug Type: CASING Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 370 ft. with 50 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set 15 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Cut and Cap Date: \_\_\_\_\_  
of \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Kathleen Spring

Title: Manager Date: 7/8/2020 Email: kathleenspring3@gmail.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Wolfe, Stephen Date: 11/30/2020

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: 5/29/2021

COA Type	Description
	<p>Venting</p> <p>Operator shall implement measures to control unnecessary and excessive venting, to protect the health and safety of the public, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.</p>
	<p>Bradenhead Testing</p> <p>Prior to starting plugging operations a bradenhead test shall be performed if there has not been a reported bradenhead test within the 60 days immediately preceding the start of plugging operations.</p> <p>1) If, before opening the bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required.</p> <p>2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required.</p> <p>The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.</p> <p>If there is a need for sampling, contact COGCC engineering for verification of plugging procedure.</p>
	<p>Plugging</p> <p>1) Provide 48 hour notice of plugging MIRU via electronic Form 42.</p> <p>2) Properly abandon flowlines as per Rule 1105. File electronic Form 42 once abandonment complete. Within 90 days of an operator completing abandonment requirements for an off-location flowline or crude oil transfer line the operator must submit a Flowline Report, Form 44.</p> <p>3) Plugs and squeezes will be placed as stated in the Plugging Procedure section of the approved NOIA unless revised by COA or prior approval from COGCC is obtained.</p> <p>4) The wellbore must be static prior to placing cement plugs which are to be a minimum of 100' in length for all but surface plugs. Mechanical isolation requires a 25' cement plug, minimum. For plugs not specified to be tagged, a tag is required if circulation is not maintained while pumping plug and displacing to depth.</p> <p>5) Place a 50' plug (minimum) at the surface, both inside the inner most casing and in all annular spaces. Surface plugs shall be circulated to surface. Confirm cement to surface in all strings during cut and cap.</p> <p>6) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed.</p> <p>7) Contact COGCC Area Inspector prior to commencing plugging operations.</p> <p>8) No current Form 17 on file with COGCC. Contact COGCC area engineer with results of pre-plugging bradenhead test for confirmation of plugging procedure prior to commencing plugging operations.</p> <p>9) After placing the shallowest hydrocarbon isolating plug (4690'), operator must wait a sufficient time on all subsequent plugs to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC Area Engineer before continuing operations.</p> <p>10) Add isolation at 1200-1100', 10 sx casing plug or CIBP with 2 sx of cement.</p> <p>11) Perforate at 370' and squeeze shoe with 50 sx of cement. WOC and tag, top of cement must be 270' or higher. Contact COGCC Area Engineer if additional cement required.</p>

### **Attachment List**

Att Doc Num	Name
402439493	FORM 6 INTENT SUBMITTED
402439507	WELLBORE DIAGRAM
402439508	WELLBORE DIAGRAM

Total Attach: 3 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Aq Det Tool- Dakota/Cheyenne Aquifer Surface Elevation (ft) Depth (ft) Top of Dakota 3418 571 Base of Dakota 3232 757 Top of Cheyenne 3172 817 Base of Cheyenne 3061 928 Dkta base + 50 =, Chey base + 50 =807', 978' WW + Elev diff + 50 = 750 + 3989 - 3975 + 50 = 814' Logs - Additional water061-05007 State Bock Unit 1 GR=4004	11/30/2020

Total: 1 comment(s)