

Document Number:  
402565917

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Jenifer Hakkarinen  
 Name of Operator: PDC ENERGY INC Phone: (303) 8605800  
 Address: 1775 SHERMAN STREET - STE 3000 Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80203 Email: Jenifer.Hakkarinen@pdce.com

**For "Intent" 24 hour notice required,** Name: Santistevan, Brittani Tel: (720) 471-1110  
**COGCC contact:** Email: brittani.santistevan@state.co.us

Type of Well Abandonment Report:  Notice of Intent to Abandon  Subsequent Report of Abandonment

API Number 05-123-26021-00  
 Well Name: EDWARDS Well Number: 43-16U  
 Location: QtrQtr: NESE Section: 16 Township: 5N Range: 67W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.397860 Longitude: -104.890750  
 GPS Data: GPS Quality Value: 1.6 Type of GPS Quality Value: \_\_\_\_\_ Date of Measurement: 07/28/2008

Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_

Casing to be pulled:  Yes  No Estimated Depth: 540  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	7776	7854			

Total: 1 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	J-55	24	0	468	330	468	0	VISU
1ST	7+7/8	4+1/2	J-55	10.5	0	7870	700	7870	586	CBL

Subsurface hazards include, but are not limited to, the following: overpressured zones, underpressured zones, major geologic faults, salt sections, H2S at concentrations greater than or equal to 100 ppm.

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7726 with 2 sacks cmt on top. CIBP #2: Depth 6917 with 2 sacks cmt on top.  
CIBP #3: Depth 2500 with 2 sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 16 sks cmt from 1430 ft. to 1230 ft. Plug Type: CASING Plug Tagged:   
Set 227 sks cmt from 668 ft. to 0 ft. Plug Type: STUB PLUG Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: \_\_\_\_\_  
Surface Plug Setting Date: \_\_\_\_\_ Cut and Cap Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105  Yes  No

#### Technical Detail/Comments:

Edwards 43-16U (05-123-26021)/Plugging Procedure (Intent)  
Producing Formation: J-Sand: 7776'-7854'  
Upper Pierre Aquifer: 360'-1330'  
TD: 7908' PBSD: 7854' (11/11/2008)  
Surface Casing: 8 5/8" 24# @ 468' w/ 330 sxs cmt  
Production Casing: 4 1/2" 10.5# @ 7870' w/ 700 sxs cmt (TOC @ 586' - CBL)

Tubing: 2 3/8" tubing set @ 7762' (6/24/2009)

Proposed Procedure:

1. MIRU. Pull 2 3/8" tubing.
2. RU wireline company.
3. TIH with CIBP. Set BP at 7726'. Top with 2 sxs 15.8#/gal CI G cement. (Top of J-Sand Perfs @ 7776')
4. TIH with CIBP. Set BP at 6917'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Niobrara @ 6967')
5. TIH with CIBP. Set BP at 2500'. Top with 2 sxs 15.8#/gal CI G cement. (Courtesy Plug)
6. TIH with casing cutter. Cut 4 1/2" casing @ 540'. Pull cut casing.
7. TIH with tubing to 1430'. Mix and pump 16 sxs 15.8#/gal CI G cement down tubing. (Pierre Coverage from 1430'-1230')
8. Wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or fluid migration, contact engineering before continuing operations
9. Pick up tubing to 668'. Mix and pump 227 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface.
10. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_

Print Name: Jenifer Hakkarinen

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_

Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: \_\_\_\_\_

<b>COA Type</b>	<b>Description</b>

**Attachment Check List**

<b>Att Doc Num</b>	<b>Name</b>
402565918	WELLBORE DIAGRAM
402565919	WELLBORE DIAGRAM

Total Attach: 2 Files

**General Comments**

<b>User Group</b>	<b>Comment</b>	<b>Comment Date</b>
		Stamp Upon Approval

Total: 0 comment(s)