

Well Name : Rosener #1
API # : 001-09001



Photo 1: Well sign.



Photo 2: Excavating around wellhead to plumb in Braden Head to surface.

Well Name : Rosener #1
API # : 001-09001



Photo 3: Braden Head plumbed to surface.



Photo 4: Access road wash out.

Well Name : Rosener #1
API # : 001-09001



Photo 5: Trench access road for culvert to repair wash out.



Photo 6: Laying in new culvert.

Well Name : Rosener #1

API # : 001-09001



Photo 7: Backfilling and compacting fill over culvert.



Photo 8: Spreading road base over repair to stabilize area.

Well Name : Rosener #1
API # : 001-09001



Photo 9: Top view of repaired access road.



Photo 10: Lower view of repaired road with new culvert.