

Well Name : LTJ partnership 13-28

API # : 123-11243



Photo 1: Excavating previously cut and capped surface casing.



Photo 2: Surface casing and cap.

Well Name : LTJ partnership 13-28

API # : 123-11243



Photo 3: Cut off surface casing to solid pipe and exposed cement plug.



Photo 4: Removing cement plug in surface casing.

Well Name : LTJ partnership 13-28

API # : 123-11243



Photo 5: Cleaned up surface casing with cement plug removed.



Photo 6: Open surface casing. Tag cement at 103'.

Well Name : LTJ partnership 13-28
API # : 123-11243



Photo 7: Welding extension into place.



Photo 8: Installed wellhead on surface casing extended to surface.

Well Name : LTJ partnership 13-28

API # : 123-11243



Photo 9: Backfilling excavate area.



Photo 10: Wellhead completed and ready for rig move in.