

FORM

6

Rev
11/20

State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

402571451

Date Received:

01/11/2021

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10330

Contact Name: Jim Chisholm

Name of Operator: INVESTMENT EQUIPMENT LLC

Phone: (405) 642-9437

Address: 412 W PLATTE AVE

Fax: (970) 867-8374

City: FT MORGAN State: CO Zip: 80701

Email: investmentequipment@gmail.com

For "Intent" 24 hour notice required,

Name: Sherman, Susan

Tel: (719) 775-1111

COGCC contact:

Email: susan.sherman@state.co.us

Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number 05-121-05320-00

Well Name: COLORADO STATE

Well Number: 1

Location: QtrQtr: NWNW Section: 36 Township: 3S Range: 53W Meridian: 6

County: WASHINGTON

Federal, Indian or State Lease Number: 60/4818-S

Field Name: BLADE

Field Number: 6900

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.753083

Longitude: -103.271594

GPS Data: GPS Quality Value: 6.0 Type of GPS Quality Value: PDOP Date of Measurement: 01/01/2004

Reason for Abandonment: ☐ Dry ☒ Production Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☐ No If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	4475	4481		CEMENT	

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	H-40	24	0	111	80	111	0	VISU
1ST	7+7/8	5+1/2	J-55	14	0	4513	100	4513	3647	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4400 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 270 ft. with 80 sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at 1200 ft. with 40 sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set 20 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing

Surface Plug Setting Date: _____ Cut and Cap Date: _____ Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____

*Wireline Contractor: _____

*Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Jim Chisholm

Title: Manager / Member Date: 1/11/2021 Email: investmentequipment@gmail.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Wolfe, Stephen Date: 3/19/2021

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 9/18/2021

COA Type	Description
	<p>Venting</p> <p>Operator shall implement measures to control unnecessary and excessive venting, to protect the health and safety of the public, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.</p>
	<p>Bradenhead Testing</p> <p>Prior to starting plugging operations a bradenhead test shall be performed if there has not been a reported bradenhead test within the 60 days immediately preceding the start of plugging operations.</p> <p>1) If, before opening the bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required.</p> <p>2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required.</p> <p>The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.</p> <p>If there is a need for sampling, contact COGCC engineering for verification of plugging procedure.</p>
	<p>Plugging</p> <p>1) Provide 48 hour notice of plugging MIRU via electronic Form 42.</p> <p>2) Properly abandon flowlines as per Rule 1105. Pursuant to Rule 911.a. Closure of Oil and Gas Facilities, Operator will submit Site Investigation and Remediation Workplans via Form 27 for COGCC prior approval before cutting and capping the plugged well, conducting flowline abandonment, and removing production equipment. Pursuant to Rule 1105.f. Abandonment Verification, within 90 days of an operator completing abandonment requirements for a flowline or crude oil transfer line, an operator must submit a Field Operations Notice, Form 42-Abandonment of Flowlines for on-location flowlines, and a Flowline Report, Form 44, for off-location flowlines or crude oil transfer lines.</p> <p>3) Plugs and squeezes will be placed as stated in the Plugging Procedure section of the approved NOIA unless revised by COA or prior approval from COGCC is obtained.</p> <p>4) The wellbore must be static prior to placing cement plugs which are to be a minimum of 100' in length for all but surface plugs. Mechanical isolation requires a 25' cement plug, minimum. For plugs not specified to be tagged, a tag is required if circulation is not maintained while pumping plug and displacing to depth. Tag at tops specified or shallower. Notify COGCC Area Engineer before adding cement to previous plug.</p> <p>5) Place a 50' plug (minimum) at the surface, both inside the inner most casing and in all annular spaces. Surface plugs shall be circulated to surface. Confirm cement to surface in all strings during cut and cap.</p> <p>6) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed.</p> <p>7) Contact COGCC Area Inspector prior to commencing plugging operations.</p> <p>8) After placing the shallowest hydrocarbon isolating plug (4400'), operator must wait a sufficient time on all subsequent plugs to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC Area Engineer before continuing operations.</p> <p>9) Add 40 sx squeeze at 1200' for upper Pierre protection. If CICR is not used, leave 100' of cement in the casing and tag if circulation is not maintained while pumping and displacing the plug to depth.</p> <p>10) Perf and pump 80 sx balanced shoe plug at 270-0'. Tag if cement is not circulated to surface. Notify per COA #4.</p> <p>11) No current Form 17 on file with COGCC. Contact COGCC area engineer with results of pre-plugging bradenhead test for confirmation of plugging procedure prior to commencing plugging operations.</p> <p>12) Reported "as drilled" GPS data is Inaccurate. Submit accurate "as drilled" GPS data on Subsequent Report of Abandonment. GPS data must meet the requirements of Rule 216.</p> <p>13) Include API No. on WBD with Form 6 SRA.</p>

Attachment List

<u>Att Doc Num</u>	<u>Name</u>
402571451	FORM 6 INTENT SUBMITTED
402571495	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Aquifer: High Plains Deepest water well: 126'(5-1mi), 156(19-2mi) Log:2/28/62 Upper Pierre base 950' CIBP at 4488', isolates perf at 4491'.	03/19/2021
OGLA	COGCC OGLA Staff conducted its review of this Form 6 Well Notice of Intent (NOI) Abandonment Report and the location in the context of SB 19-181 and the current rules. This Form 6 complies with COGCC Rules and is adequately protective of public health, safety, welfare, the environment, and wildlife resources.	03/17/2021

Total: 2 comment(s)