





Daily Operations

Well Name: NOVACEK C28-07

Daily Operations				
Well Name	API	Job Type	Start Date	Summary
NOVACEK C28-07	05-123-23745	REPAIR WELLHEAD	10/22/2020	10/22/20 CREW AND EQUIP TO LOCATION. HELD SAFETY MTG. SPOTTED IN EQUIP AND RIG. RU SPN 714 AND PUMP AND TANK. PRESSURE TEST ALL SURF EQUIP AND BOPS. IWP 1265/1265# SURF 0#. RU RPS AND STARTED FLARING OFF GAS. IN 2 HOURS WELL BLEW DOWN TO 1000#
NOVACEK C28-07	05-123-23745	REPAIR WELLHEAD	10/23/2020	10/23/20 CREW TO LOCATION. HELD SAFETY MTG. W/ALL ON LOCATION. IWP 1250/1250#. SURF 0#. PRESSURE TEST ALL SURF EQUIP AND BOPS. STARTED FLARING OFF GAS. CIRCULATED WELL BORE CLEAN OF OIL AND GAS. LET SET FOR 5 MIN. WELL STATIC. ND WELL HEAD AND UNLAND TBG. CHG OUT O-RINGS ON MANDREL. LAND TBG. NU WELL HEAD. REMOVED SURF CAP AND CHG OUT PACKING RUBBER. MU CAP AND TIGHTED. LET WELL SET FOR 30 MIN. CHECK SURF AND IT IS STILL LEAKING. CALLED IN FOR ORDERS. ND WELL HEAD AND NU BOPS. TEST BOPS AND WELL HEAD. UNLAND TBG AND POOH
NOVACEK C28-07	05-123-23745	REPAIR WELLHEAD	10/27/2020	10/27/20 CREW TO LOCATION. HELD SAFETY MTG. IWP 0/0# SURF 0#. WORKED AT STARTING EQUIP AND RIG. WARMED UP RIG AND EQUIP. HELD SAFETY MTG. W/ALL ON LOCATION. RU SPN WIRELINE. PICKED UP CIBP AND TIH. SET CIBP AT 6580' KB. POOH AND LAID DOWN SETTING TOOL. PICKED UP BAILER AND TIH. DUMP 2 SKS CMT ON TOP OF CIBP. POOH AND RD WIRELINE. LOAD CSG AND PRESSURE TEST TO 500# AND HELD FOR 15 MIN. GOOD TEST. BLED PRESSURE OFF. RD FLOOR AND ND BOPS. HELD SAFETY MTG W/ALL ON LOCATION PICKED UP SPEAR. PULLED ON CSG AND STRAIGHTEN UP SLIPS IN SURF HEAD. PACKED OFF SURF HEAD AND LET STAND FOR 30 MIN. AND CHECK FOR BUBBLES. AFTER 30 MIN NO BUBBLES. TIH W/31 JTS POOH AND LAID DOWN.. PICKED UP NC AND SN AND TIH W/178 JTS 5856.2'. LAND TBG. RD FLOOR AND ND BOPS. NU WELL HEAD W/MASTER VALVE. SECURE WELL SDFN