



Kerr-McGee Oil & Gas Onshore LP

1099 18th Street
Denver, CO 80202
720-929-6000

REI 26-5

API: 05-123-32973

1. Slickline
 - a. Tag/pull production equipment as needed
 - b. Set tubing plugs as needed
2. WH/Pad work
 - a. Prep pad for workover rig
 - b. Remove WH/flowline equipment as needed
 - c. Rig up flowback equipment as needed
3. Workover Rig
 - a. MIRU workover rig
 - b. NU BOPS
 - c. TOH with production tubing & packer
 - d. Pick up cleanout BHA
 - e. Cleanout well
 - f. Pick up production string with packer
 - g. ND BOPS and NU WH equipment
4. WH/Pad work
 - a. Rebuild WH/flowline equipment as needed
 - b. Swab if needed to kick well off

Workover rig operations will be daylight hours