



Maintenance/Installation Notes:

- Anchor as necessary
- Install outlet protection with riprap, matting, or wattles, and/or vegetation buffer depending on flow volume
- Maintain outlet protection if $\frac{1}{2}$ " or more of sediment accumulates, or flow increases the need to increase protection.
- 4" to 8" diameter pipe