

**From:** [Bear, Chris \[NES\]](#)  
**To:** [Sanford, Anita S](#)  
**Subject:** Gray A 11 Cement top job details  
**Date:** Thursday, September 30, 2021 4:13:22 PM

---

Anita! We performed the top job as follows;

Cut off 10 ¾" surface casing and 7" prod csg 6' below ground level  
Top off prod csg w/ 1 bbl fresh wtr, surface csg annulus already full of wtr  
Install 60' of 1" pvc, into prod csg, Tag TOC @ 60'  
Back in Cement truck, Dump 2.4 bbls (11.5 sks) 15.8 ppg 1.15 yield G neat slurry and displace wtr up 1"  
pvc pipe until slurry all the way around  
Remove PVC from prod csg, Install into 7"x10 ¾" annulus  
Dump 3 bbls (15 sks) 15.8 ppg 1.15 yield G neat slurry and displace wtr up 1" pvc until slurry all the way around  
Remove pvc and top off both sides  
Begin 5 day monitoring prior to capping. Monitor begins 9/30/2021 @ 1200

Thanks,

Chris Bear ●●  
Well Site Representative  
Chevron MCBU  
[chrisbear@chevron.com](mailto:chrisbear@chevron.com)  
[bigbearconsultingllc@gmail.com](mailto:bigbearconsultingllc@gmail.com)  
970-589-9052