

FORM  
6Rev  
11/20

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

402897299

Date Received:

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Valerie Danson

Name of Operator: PDC ENERGY INC

Phone: (970) 506-9272

Address: 1775 SHERMAN STREET - STE 3000

Fax:

City: DENVER State: CO Zip: 80203

Email: valerie.danson@pdce.com

**For "Intent" 24 hour notice required,**

Name: Evins, Bret

Tel: (970) 420-6699

**COGCC contact:**

Email: bret.evins@state.co.us

Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number 05-123-22515-00

Well Name: FRANCIS

Well Number: 22-8

Location: QtrQtr: SENW Section: 8 Township: 6N Range: 64W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.501890

Longitude: -104.577110

GPS Data: GPS Quality Value: 2.8 Type of GPS Quality Value: Date of Measurement: 01/11/2007

Reason for Abandonment: ☐ Dry ☒ Production Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA-CODELL	6718	7034			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	J55	24	0	541	541	541	0	VISU
1ST	7+7/8	4+1/2	J55	10.5	0	7218	490	7218	2844	CBL
S.C. 1.1						2844	387	2844	0	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6668 with 2 sacks cmt on top. CIBP #2: Depth 3490 with 2 sacks cmt on top.  
CIBP #3: Depth 2500 with 2 sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 126 sacks half in. half out surface casing from 1660 ft. to 0 ft. Plug Tagged: ☒

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing

Surface Plug Setting Date: \_\_\_\_\_ Cut and Cap Date: \_\_\_\_\_ Number of Days from Setting Surface Plug to Capping or Sealing the Well: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_

\*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

#### Technical Detail/Comments:

Francis 22-8 (05-123-22515)/Plugging Procedure (Intent)  
Producing Formation: Niobrara/Codell: 6718'-7034'

Upper Pierre Aquifer: 500'-1560'

TD: 7252' PBTD: 7252' (11/7/11)

Surface Casing: 8 5/8" 24# @ 541' w/ 541 sxs cmt

Production Casing: 4 1/2" 10.5# @ 7218' w/ 490 sxs (TOC @ 2844' - CBL)

Annular fill @ 2844' w/ 387 sxs (TOC @ Surface - CBL)

Tubing: 2 3/8" tubing @ 7008' (11/17/11)

Proposed Procedure:

1. MIRU pulling unit. Pull 2 3/8" tubing.

2. RU wireline company.

3. TIH with CIBP. Set BP at 6668'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Nio perms @ 6718')

4. TIH with CIBP. Set BP at 3490'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Parkman @ 3540')

5. TIH with CIBP. Set BP at 2500'. Top with 2 sxs 15.8#/gal CI G cement.

6. Wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or fluid migration, contact engineering before continuing operations.

7. TIH with tubing to 1660'. RU cementing company. Mix and pump 126 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface. (Pierre coverage from 1660' to Surface)

8. Well casing cut and capped per COGCC guidelines at a depth as not to interfere with soil cultivation.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Valerie Danson  
Title: Reg Tech Date: \_\_\_\_\_ Email: valerie.danson@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

**COA Type** **Description**

--	--

**Attachment List**

**Att Doc Num** **Name**

402897302	WELLBORE DIAGRAM
402897303	WELLBORE DIAGRAM

Total Attach: 2 Files

**General Comments**

**User Group** **Comment** **Comment Date**

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)