

**Proposed re-abandonment procedure for Schureman #1 well.**

**Verify there is no pressure in surface casing. Survey well location as specified by COGCC. Excavate approximately 6' below base of mine. Cut off casing approximately 4' below base of mine. Pump 10 sks cmt in 8 5/8" casing. Weld on cap with weep hole and attach required well identification. Fill excavated area around cut off casing. No additional reclamation will be necessary as mine will be used for water storage.**