



Kerr-McGee Oil & Gas Onshore LP

1099 18th Street
Denver, CO 80202
720-929-6000

Sandau 23-34

API: 05-123-16270

1. WH/Pad work
 - a. Prep pad
 - b. Remove flowline/WH components as needed
 - c. Fish slickline equipment as needed
2. Rig work
 - a. MIRU/NU BOPs
 - b. TOH with w/ tubing
 - c. Run bit/scraper as needed
 - d. TIH and set packer at 6900' with tubing to surface
 - e. ND BOPSS/RDMO
3. WH/Pad work
 - a. Reinstall/replace WH/flowline components as needed
4. Post rig MIT
 - a. Turn in 10 day notice
 - b. Pressure test casing to 500 psi for 15 minutes and obtain MIT

Operations will be daylight hours