

# OIL AND GAS CONSERVATION COMMISSION OF THE STATE OF COLORADO

File in duplicate for Patented and Federal lands.  
File in triplicate for State lands.

RECEIVED  
NOV 20 1978  
COLO. OIL & GAS COM.



## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO.
2. NAME OF OPERATOR Petroleum, Inc.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P.O. Box 60, Casper, WY 82601		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 695' FNL 1955' FWL C/ NE NW At proposed prod. zone		8. FARM OR LEASE NAME Ramrod
14. PERMIT NO. 68-503		9. WELL NO. 3-1
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4552 KB		10. FIELD AND POOL, OR WILDCAT Ramrod
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 33-12N-55W
		12. COUNTY OR PARISH 13. STATE

### 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

#### NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON

CHANGE PLANS

#### SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Propose to plug & abandon well - Economically infeasible to operate - will proceed when approval received.

#### PLUGGING INSTRUCTIONS:

1. Run sand over perforations plus 5 sacks cement on top of sand.
2. Cut and pull pipe.
3. Run 15 sacks cement plug at base of surface casing.
4. Run 5 sacks plug at surface with a welded steel plate on the stub; cut off 3 feet below the surface.

DVR	
FJP	
HHM	
JAM	
JJD	
RLS	
CGM	

18. I hereby certify that the foregoing is true and correct

SIGNED

*P. H. Julius*

TITLE

DIRECTOR  
O & G CON. COM.

DATE

NOV 20 1978

(This space for Federal or State office use)

APPROVED BY

*W. Rogers*

TITLE District Production Supt.

DATE Nov. 16, 1978

CONDITIONS OF APPROVAL, IF ANY:

X