

OGEC FORM 4
Rev. 8/89STATE OF COLORADO
OIL AND GAS CONSERVATION COMMISSION
DEPARTMENT OF NATURAL RESOURCES

SUBMIT ORIGINAL AND 1 COPY



FOR OFFICE USE ONLY			
ET	FE	UC	SE

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

5 FEDERAL INDIAN OR STATE LEASE NO.

☒ OIL WELL ☐ GAS WELL ☐ COALBED METHANE ☐ INJECTION WELL ☐ OTHER6 PERMIT NO
67-2437 NAME OF OPERATOR
Western Operating Company7 API NO
05-061-60118 ADDRESS OF OPERATOR
518 - 17th Street, Suite 16808 WELL NAME
HarrisonCITY STATE ZIP CODE
Denver CO 802029 WELL NUMBER
No. 34 LOCATION OF WELL (Report location clearly and in accordance with any State requirements
See also space 17 below.)
At surface 1980' FEL & 660' FNL of Sec. 910 FIELD OR WILDCAT
Brandon

At proposed prod zone Same

12 COUNTY
Kiowa11 QTR QTR SEC. T.R. AND MERIDIAN
SWNE Section 9
T19S-R45W

Check Appropriate Box To Indicate Nature of Notice, Report or Notification

13A. NOTICE OF INTENTION TO:

- ☒ PLUG AND ABANDON
- ☐ MULTIPLE COMPLETION
- ☐ COMMINGLE ZONES
- ☐ FRACTURE TREAT
- ☐ REPAIR WELL
- ☐ OTHER

13B. SUBSEQUENT REPORT OF:

- ☐ FINAL PLUG AND ABANDONMENT
(SUBMIT 3RD PARTY CEMENT VERIFICATION
AND JOB LOG)
- ☐ ABANDONED LOCATION (WELL NEVER DRILLED -
SITE MUST BE RESTORED WITHIN 6 MONTHS)
- ☐ REPAIRED WELL
- ☐ OTHER

*Use Form 5 - Well Completion or Recompletion Report and Log
for subsequent report of Multiple/Commingle Completions
and Recompletions

13C. NOTIFICATION OF:

- ☐ SHUT-IN TEMPORARILY ABANDONED
(DATE _____)
(REQUIRED EVERY 6 MONTHS)
- ☐ PRODUCTION RESUMED
(DATE _____)
- ☐ LOCATION CHANGE (SUBMIT NEW PLAT)
- ☐ WELL NAME CHANGE
- ☐ OTHER

14 DESCRIBE PROPOSED OR COMPLETED OPERATIONS ON THIS FORM (Clearly state all pertinent details, and give pertinent dates, including
estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and
zones pertinent15 DATE OF WORK Third (3rd) Quarter, 1996

1. Freepoint & back off stuck 2-7/8" tbg. If backoff is below 4200'. Set CIBP above backoff w/2 sx cement spotted on top of CIBP. If backoff is above 4200', set cement retainer on top of backoff. Squeeze 100 sx cement through retainer. Spot 2 sx on top of retainer. Fill hole w/water. If hole doesn't load spot 10 sx plug @ 1500'±. Let cement set up. Load hole w/water.
2. Perf 4 holes in csg @ 1300'±. Set cement retainer @ 1250'±. Squeeze 113 sx cement through retainer. Spt 2 sx on top of retainer.
3. Perf 4 holes in csg @ 205'±. Pump 25 sx cement out of 5-1/2 csg & 25 sx inside csg.
4. Set 10 sx plug @ surface. Put 5 sx in 8-5/8" & 5 sx in 5-1/2" csg. Cut off 8-5/8" & 5-1/2" csg - 4'± below ground level. Weld on 1/4" or thicker cap that reads - Harrison #3 - SWNE Sec. 9-T19S-R45W.
5. Reclaim location.

16. I hereby certify that the foregoing is true and correct

SIGNED

TELEPHONE NO. (303) 893-2438

NAME (PRINT) Steven D. James

TITLE Vice President

DATE March 29, 1996

(This space for Federal or State office use)

APPROVED

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: