

API# 05-123-07158
Rig/ Sup Bohler/Eisenach
Job Type Re-entry P&A
AFE# 2023CO29-37 Split



Month of April 2023
Location: NENE 30 2N64W 6 PM

Kaminsky #1

Well Info

- Surface: 8-5/8" 28# @ 308'. Cement: Surface VISU
- Production: Open hole, assumed 7-7/8", no documentation found in well files
- KB: 10'. Last W/O 4/11/1970 (P&A dryhole)
- Using 30% excess cement for all open hole plugs

Procedure

** Verdad will be using a closed-loop recirculating returns system consisting of shaker tank, mud tank, cuttings bin, and a utility tank to divert fluid to for solids to settle out, fluid for disposal, etc.**

1. File Form 42 2 days prior for P&A ops, notify COGCC field engineer of ops commencing
2. Familiarize all personnel with allowed access to location and areas allowed to be disturbed
3. Secure permission to access area and identify prospective well locations via satellite and survey data
4. Verify well location and excavate well
5. Once permission to begin work is secure, excavate area around well to sufficient size for safe access of casing, verify casing size, cut off cap, weld on slip collar w/ wellhead and riser, set cellar ring and back-fill
6. MIRU WO rig and beam, BOP, accumulator, rig pump, shaker tank, rig tank, 9.5ppg water-based mud, pipe float, 3-1/8" collars, 2-7/8" EUE work string, power swivel
7. Rig up tubing tools, NU BHA and function test
8. Make up BHA consisting of: 2-7/8 EUE string, 2x 3-1/8" drill collars, float, POBS, and 6.5" roller-cone bit
9. RIH and drill out previous cement plugs from 0-30' and estimated TOC 250' – 308'
10. Wash or ream in 7-7/8" open hole to 7,650'
11. Circulate and condition hole
12. TOOH and laydown BHA
13. RIH w/ 4.75" Tricone mill, XO, string float to 7,630'. Circulate and condition hole, if circulation is not established, contact engineer
14. MIRU cementers and pump 60 sks of Class G, 15.8 ppg, 1.15 yield cement from 7,630' – 7,480' to isolate the D Sand Formation. Displace and POOH through cement and release cementers, ensure that EOT is a minimum 100' above cement top before WOC
15. WOC 4 hours or otherwise advised by cementers and tag cement. If not tagged at or above 7,480', contact engineer. May require additional cement
16. MIRU cementers and pump 115 sks of Class G, 15.8 ppg, 1.15 yield cement from 6,930' – 6,630' to isolate the Niobrara Formation. Displace and POOH through cement and release cementers, ensure that EOT is a minimum 100' above cement top before WOC



API# 05-123-07158
Rig/ Sup Bohler/Eisenach
Job Type Re-entry P&A
AFE# 2023CO29-37 Split

Month of April 2023
Location: NENE 30 2N64W 6 PM

17. WOC 4 hours or otherwise advised by cementers and tag cement. If not tagged at or above 6,780', contact engineer. May require additional cement
18. POOH to 2550', circulate and condition hole. RU cementers and pump 60 sks of Class G, 15.8 ppg, 1.15 yield cement from 2,550' – 2,400' to isolate the Upper Pierre Formation/Courtesy Plug. Displace and POOH through cement and release cementers, ensure that EOT is a minimum 100' above cement top before WOC
19. WOC 4 hours or otherwise advised by cementers and tag cement. If not tagged at or above 2,400', contact engineer. May require additional cement
20. POOH to 967', circulate and condition hole. **Prior to placing the Fox Hills Aquifer plug, verify that all fluid (liquid and gas) migration has been eliminated. If evidence of fluid migration or pressure remains, contact engineer to verify with the COGCC for an update to plugging orders**
21. If no fluid migration, RU cementers and pump 115 sks of Class G, 15.8 ppg, 1.15 yield cement from 967' – 667' to isolate the Fox Hills Aquifer. Displace and POOH through cement and release cementers, ensure that EOT is a minimum 100' above cement top before WOC
22. WOC 4 hours or otherwise advised by cementers and tag cement. If not tagged at or above 817', contact engineer. May require additional cement
23. POOH to 358', circulate and condition hole. RU cementers and pump cement until returns taken to surface, 130 sks of Class G, 15.8 ppg, 1.15 yield cement estimated. Once good returns taken, SD cement and POOH. Top off as necessary
24. RDMO cementers, rig, and supporting equipment. Tidy location and prep for reclamation
25. After 5 days, verify TOC is within 5' of surface. Top off if needed. Excavate cellar ring and wellhead, cut off casing 6' below ground level and weld on cap with full legal description welded onto plate. Back fill hole
26. Reclaim location
27. Submit Form 6 Subsequent and Form 42 for completion of COA