

WMSSU 35-4

Description of Flowline Abandonment per Rule 1105

The subject well has had the flowlines capped near the wellbore to undergo plugging and abandonment in March of 2023. After the growing season & harvest, the following flowline abandonment procedure will be undertaken. The estimated latest date of this Procedure is November 30th, 2023.

- 1) Field Production will be shut-in and flowline will be evacuated at the nearest riser utilizing a vac truck. OOSLAT procedure will be followed.
- 2) When flowlines have been evacuated, an excavation to sever the flowline will be performed. This excavation will take place at least 30' East of the road & water transfer ditch. Soil will be sampled at this location per rule 915-1. The remaining flowline stubs will be capped.
- 3) The flowlines will be excavated along the path of the flowline to the wellhead.
- 4) When the flowlines are removed, the soil will be sampled at the flowline riser near the well.
- 5) The excavated and abandoned flowline along with any stained soils (if found) will be transported for appropriate disposal.
- 6) Additional soil samples will be taken as required by table 915-1
- 7) When the soil samples meet State requirements, the excavations will be backfilled
- 8) The surface will be restored to the surface owner's satisfaction.