



00202276

or Patented and Federal lands.  
File in triplicate for State lands.RECEIVED  
DEC 1 1986**SUNDRY NOTICES AND REPORTS ON WELLS**  
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

5. LEASE DESIGNATION &amp; SERIAL NO.

6. IF INDIAN ALLOTTEE OR TRIBE NAME

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR Joseph P. Doyle		8. FARM OR LEASE NAME McDermott	
3. ADDRESS OF OPERATOR Box 1387, Steamboat Springs, Co 80477		9. WELL NO. #1 McDermott	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 675' FSL, 2003' FEL, Sec. 24, T6N, R86W At proposed prod. zone Routt County, Co.		10. FIELD AND POOL, OR WILDCAT Curtis	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA SW SE, Sec. 24 T6N R86W	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.)	12. COUNTY Routt	13. STATE Co

## 16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL.

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON

CHANGE PLANS.

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

18. Date of work

11/14/86

\* Must be accompanied by a cement verification report.

1. Move in rig.
2. RIH with tubing to 2610'. Could get no deeper. Top of 7" stub.
3. Spot 20 sack cement plug at 2610'.
4. Pull up and spot 35 sack plug 50' in & 50' out of bottom of surface casing at 586'.
5. Pull up and run 10 sack plug at surface.
6. Cut off surface below plow depth and weld plate on.
7. Clean location & move off.

19. I hereby certify that the foregoing is true and correct

SIGNED

W. J. Ruppert Jr.

TITLE

President (Ruppert Inc.)

DATE

11/22/86

(This space for Federal or State office use)

APPROVED BY

G. A. [Signature]

TITLE

SUPR. PETROLEUM ENGINEER  
Oil & Gas Cons. Comm.

DATE

DEC 03 1986

CONDITIONS OF APPROVAL, IF ANY:

R