

Document Number:
403455394

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Valerie Danson

Name of Operator: PDC ENERGY INC Phone: (970) 506-9272

Address: 1099 18TH STREET SUITE 1500 Fax: _____

City: DENVER State: CO Zip: 80202 Email: regulatory@pdce.com

For "Intent" 24 hour notice required, Name: Peterson, Tom Tel: (970) 370-1281

COGCC contact: Email: tom.peterson@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-123-33243-00

Well Name: Zeiler Well Number: 23-7DU

Location: QtrQtr: SWSW Section: 7 Township: 5N Range: 67W Meridian: 6

County: WELD Federal, Indian or State Lease Number: _____

Field Name: WATTENBERG Field Number: 90750

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.410140 Longitude: -104.941220

GPS Data: GPS Quality Value: 1.6 Type of GPS Quality Value: PDOP Date of Measurement: 03/29/2012

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems

Other _____

Casing to be pulled: Yes No Estimated Depth: 700

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA-CODELL	7098	7421			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	J55	24	0	438	320	438	0	VISU
1ST	7+7/8	4+1/2	J55	11.6	0	8018	460	8018	1180	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7048 with 2 sacks cmt on top. CIBP #2: Depth 4234 with 2 sacks cmt on top.
CIBP #3: Depth 2500 with 2 sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 10 sks cmt from 1650 ft. to 1450 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 375 sacks half in. half out surface casing from 750 ft. to 0 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing

Surface Plug Setting Date: _____ Cut and Cap Date: _____ Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____

*Wireline Contractor: _____

*Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

Zeiler 23-7DU (05-123-33243)/Plugging Procedure (Intent)
Producing Formations: Niobrara/Codell: 7098' – 7421'

Upper Pierre Aquifer: 630'-1550'

TD: 8035' PBTD: 7328' (4/24/12)

Surface Casing: 8 5/8" 24# @ 438' w/ 320 sxs cmt

Production Casing: 4 1/2" 11.6# @ 8018' w/ 460 sxs (TOC @ 1180' – CBL)

Tubing: 2 3/8" tubing @ 7400' (8/7/15)

Proposed Procedure:

1. MIRU pulling unit. Pull 2 3/8" tubing.
2. RU wireline company.
3. TIH with CIBP. Set BP at 7048'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Nio perms @ 7098')
4. TIH with CIBP. Set BP at 4234'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Sussex @ 4284')
5. TIH with CIBP. Set BP at 2500'. Top with 2 sxs 15.8#/gal CI G cement.
6. Wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or fluid migration, contact engineering before continuing operations.
7. TIH with tubing to 1650'. RU cementing company. Mix and pump 10 sxs 15.8#/gal CI G cement down tubing. (Pierre coverage from 1650'-1450')
8. TIH with casing cutter. Cut 4 1/2" casing @ 700'. Pull cut casing.
9. TIH with tubing to 750'. Mix and pump 375 sxs 15.8#/gal CI G cement down tubing) Cement should circulate to surface.
10. Well casing cut and capped per COGCC guidelines at a depth as not to interfere with soil cultivation.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____

Print Name: Valerie Danson

Title: Reg Analyst

Date: _____

Email: valerie.danson@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

COA Type

Description

0 COA	

Attachment List

Att Doc Num

Name

403455516	WELLBORE DIAGRAM
403455519	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)